Original		Rechange	
POWER	Power		Power
TV/RADIO	Eject	SURROUND	Eject / Surround
TV/RADIO	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
GOTO	Red/Goto	NETFLIX SEARCH	Red / Netflix / Search
GOTO	Red/Goto	SHIFT + GOTO TEXT	Shift + Text /
ANGLE	Green/Angle	ANGLE INFO	Info / Angle
ANGLE	Green/Angle	APP REPEAT	Green / APP / Repeat
REPEAT	Yellow/Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
REPEAT	Yellow/Repeat	YouTube REPEAT A-B	Yellow / YouTube / Repeat
A-B	Blue/A-B	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
A-B	Blue/A-B	Prime Video RANDOM	Blue / Prime Video / Random
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
TEXT	Text	GOTO TEXT	Text / Goto
HOLD FREEZE	Freeze/Hold	SHIFT + HOLD	Shift + Stop /
HOLD FREEZE	Freeze/Hold	SHIFT + STEP-FREEZE	Shift + Pause / Step /
EPG D.MENU	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
EPG D.MENU	D.Menu	TOP MENU D.MENU	D.Menu / Top Menu

Original		Rechange	
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
SIZE ZOOM	Zoom/Size	SIZE ZOOM	Zoom / Size
ASPECT	Aspect	SHIFT + FORMAT PICTURE	Shift + Picture / Format
SUBPAGE	Subpage	SHIFT + EQ SUBTITLE	Shift + Subtitle / EQ
MEDIA	Media	SHIFT + MEDIA DISPLAY	Shift + Display / Media
▶II	Play	SLOW ▶	Play / Slow
▶II	Pause	STEP-FREEZE II	Pause / Step / Freeze
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
D.SETUP	Rec	REC MODE	Rec / Rec Mode
D.SETUP	D.Setup	OPT-TOOLS SETUP	Setup / OPT /
■	Stop	HOLD ■	Stop / Hold
I◀◀	I<<	PRESET- I◀◀	I<< / Preset-
INDEX ▶▶I	>>I/Index	PRESET+ ▶▶I	>>I / Preset+
INDEX ▶▶I	>>I/Index	LIST SMART	Smart / List
MENU	Menu	HOME MENU	Menu / Home
LANG AUDIO	Lang/Audio	LANG I/II AUDIO	Audio / Lang I/II

Original		Rechange	
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
	Down		Down
EXIT TITLE	Title/Exit	SHIFT + TITLE SOUND	Shift + Sound / Title
EXIT TITLE	Title/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
+ VOL	Vol +	+ VOL	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
+ CH	CH+	+ CH PAGE	CH+ / Page+
VOL –	Vol -	VOL –	Vol -
DISPLAY	Display	MEDIA DISPLAY	Display / Media
CH –	CH-	CH PAGE –	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3

Original		Rechange	
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	-/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
0	0	HDMI - SAT 0	0
	Recall	RETURN BACK	Back / Return
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
P-MODE	P. Mode	FORMAT PICTURE	Picture / Format
S-MODE	S. Mode	TITLE SOUND	Sound / Title