Original		Rechange	
STANDBY	Standby		Power
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
P.MODE	P. Mode	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
S.MODE	S. Mode	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II
FREEZE	Freeze	PROGRAM TV/RADIO	TV/Radio /
TXT	TXT	OPT-TOOLS SETUP	Setup / OPT /
FAV.LIST MIX	Mix/FAV List	PC FAV MARKER	Fav / Marker / PC
SUBTITLE SIZE	Size	TIMER SLEEP	Sleep / Timer
SUBTITLE SIZE	Subtitle	EQ SUBTITLE	Subtitle / EQ
AUDIO CANCEL	Cancel / Audio	LANG I/II AUDIO	Audio / Lang I/II
RECORD	Record	REC MODE	Rec / Rec Mode
INDEX	<< / Index	TUNE+	>> / Tune+
HOLD	>> / Hold	PRESET-	I<< / Preset-

Original		Rechange	
REVEAL	I<< / Reveal	TUNE-	<< / Tune-
SUBPAGE	>>I / Subpage	PRESET+	>>I / Preset+
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
TIMESHIFT	Play	SLOW	Play / Slow
TIMESHIFT	Pause/Timeshift	STEP-FREEZE	Pause / Step / Freeze
	Down		Down
EPG	Stop	HOLD	Stop / Hold
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
+ VOL	Vol +	+ VOL	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
CH	CH+	+ CH PAGE	CH+ / Page+
VOL −	Vol -	VOL −	Vol -

Original		Rechange		Original	Rechange
TV/RADIO	Tv/ Radi o	SIZE ZOOM	Zoom / Si ze		
CH	CH-	CH PAGE	CH- / Page-		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
DISPLAY	Di spl ay	ANGLE INFO	I nf o / Angl e		
0	0	HDMI - SAT 0	0		
RECALL	Recal l	RETURN BACK	Back / Ret ur n		