Original		Rechange	
I/⏻	Power		Power
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
SLOW – TUNIN	<<</<ISlow/Tunin	TUNE-	<< / Tune-
SLOW UNING +	Tuning+/Slow	TUNE+	>> / Tune+
PREV – PRES	I<<</Preset-	PRESET-	I<< / Preset-
NEXT RESET +	>>I/Preset+	PRESET+	>>I / Preset+
BASS LEVEL	Bass Level	TITLE SOUND	Sound / Title
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
	Open/Close	SURROUND	Eject / Surround
BAND	Band	FORMAT PICTURE	Picture / Format
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TV/ VIDEO	Tv/Video	PROGRAM TV/ RADIO	TV/Radio /
DVD MENU	DVD Menu	TOP MENU D.MENU	D.Menu / Top Menu

Original		Rechange	
DVD SETUP	DVD Setup	OPT-TOOLS SETUP	Setup / OPT /
NAME	Name	GOTO TEXT	Text / Goto
AMP MENU	AMP Menu	HOME MENU	Menu / Home
	Up		Up
ANGLE	Angle	ANGLE INFO	Info / Angle
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
VOLUME	Vol+	+ VOL	Vol+
MEMORY	Memory	LIST SMART	Smart / List
	Vol-	VOL –	Vol-
DISPLAY	Display	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2

Original		Rechange	
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
>10	>10	GUIDE EPG	Guide / EPG / -/--
10/0 0	0	HDMI - SAT 0	0
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
PLAY MODE	Play Mode	SHIFT + SLOW ▶	Shift + Play /
STEREO/MONO	Stereo/Mono	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II
FUNCTION	Function	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
DVD TOP MENU	DVD Top Menu	SHIFT + HOME MENU	Shift + Menu /
SOUND FIELD +	Sound Field+	SHIFT + + VOL	Shift + Vol+
NIGHT MODE	Night Mode	SHIFT + LIST SMART	Shift + Smart / List
–	Sound Field-	SHIFT + VOL –	Shift + Vol-

Original		Rechange	
ENTER	Enter1	SHIFT + TV 1	Shift + 1
DVD DISPLAY	DVD Display	SHIFT + DVD 2	Shift + 2

Original		Rechange		Original	Rechange
TV I/⏻	Power Tv		Power		
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
>10	0/10	HDMI - SAT 0	0		
>10	-/--	-/-- GUIDE EPG	Guide / EPG / -/--		
ENTER	Enter	OK	OK		
TV VOL +	Tv Vol+	+ VOL	Vol+		
TV CH +	Tv CH+	+ CH PAGE	CH+ / Page+		
–	Tv Vol-	VOL –	Vol-		
–	Tv CH-	CH PAGE –	CH- / Page-		