Mandis shop

COV30748163

| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| FUNCTION | Function | TOP MENU MENU | Menu |
| VOL + | Vol+ | VOL + | Vol + |
| VOL − | Vol- | VOL − | Vol - |
| MUTE | Mute | MUTE | Mute |
| | Equalizer | HOME SMART | Smart |
| WOOFER LEVEL ^ | Woofer Level | CH + | Ch + |
| WOOFER LEVEL v | Woofer Level | CH − | Ch - |
| DRC | DRC | APP MEDIA | Media |
| REPEAT | Repeat | REPEAT TEXT | Text |
| | Moon | FAV PRE-CH | Pre Ch |
| SOUND EFFECT | Sound Effect | SOUND DUAL | Dual |
| >>I | >>I | >>I | >>I |
| I<< | I<< | I<< | I<< |
| ▶II | Play | PLAY MODE ▶ | Play |
| ▶II | Pause | II | Pause |
| ■ | Stop | ■ | Stop |

| Original | | Rechange | |
|---|---|---|---|
| + FOLDER | Folder + | | Up |
| FOLDER − | Folder- | | Down |
| AV.SYNC | AV Sync | TIMER AV | AV |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| VOLUME AUTO | Auto Volume | 0 | 0 |
| AUTO POWER | Auto Power | - / -- GUIDE | Guide |
| OPTICAL | Optical | SETTINGS OPT | Options |
| USB | USB | AD SUBT | Subt |
| | Bluetooth | ECO 3D | 3D |
| LG TV | LG Tv | SEARCH TV/R | TV/R |
| PORT.IN | Port.In | PICTURE FORMAT | Format |
| INFO | Info | DISPLAY INFO | Info |

https://telecommandes-mandis.be/fr/LG/1059418-86046-telecommande-de-remplacement-pour-LG-COV30748163.html