Mandis shop

RM-SCP100

Original		Rechange	
	Power		Power
DSG	DSG	SOUND DUAL	Dual
DISPLAY	Display	DISPLAY INFO	Info
CD	Play CD	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
TUNER/BAND	Play	APP MEDIA	Media
	I<< / Tuner -		I<<
	>>I / Tuner +		>>I
TAPE	Play / Rev Tape	SHIFT + PLAY MODE	Shift + Play
	<<		<<
	>>		>>
DIR MODE	Dir Mode	1	1
PLAY MODE	Play Mode	2	2
REC	Rec	REC MODE	Rec
CD REPEAT	CD Repeat	HOME SMART	Smart
STEREO/MONO	Stereo / Mono	SETTINGS OPT	Options

Original		Rechange	
TUNING MODE	Tuning Mode	3	3
MEMORY	Up/Memory		Up
TIMER SET	Left/Timer Set		Left
ENTER ON/OFF	Enter/On/Off	OK	Ok
TIMER SELECT	Right/Timer		Right
SLEEP	Down/Sleep		Down
SLEEP	Down/Sleep	SHIFT +	Shift + Power
VOL	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -

https://telecommandes-mandis.be/fr/Sony/1059676-81384-telecommande-de-remplacement-pour-Sony-RMSCP100.html