Mandis shop

Sharp RRMCGA178AWSA

Original		Rechange	
ON/STAND-BY	Standby		Power
DOLBY VIRTUAL	Virtual Speaker	SOUND DUAL	Dual
STANDARD	Standard	PICTURE FORMAT	Format
CINEMA/GAME	Cinema/Game	APP MEDIA	Media
SPORT	Sport	HOME SMART	Smart
NEWS	News	DISPLAY INFO	Info
VOLUME +	Vol+	VOL +	Vol +
VOLUME −	Vol-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
SUBWOOFER LEVEL ^	Level Subwoofer		Up
SUBWOOFER LEVEL v	Level Subwoofer Down		Down
BASS/TREBLE	Bass/Treble	REPEAT TEXT	Text
DIMMER	Dimmer	DISC NAV LIST	List
LINE	Line	PROG SLEEP	Sleep
DIGITAL 1	Digital 1	1	1
DIGITAL 2	Digital 2	2	2
ON/STAND-BY	Standby Tv	SHIFT +	Shift + Power

Original		Rechange	
INPUT	Input	TIMER AV	AV
CHANNEL ^	CH+ Tv	CH +	Ch +
CHANNEL v	CH- Tv	CH −	Ch -
VOLUME +	Vol+ Tv	SHIFT + VOL +	Shift + Vol +
VOLUME −	Vol- Tv	SHIFT + VOL −	Shift + Vol -

https://telecommandes-mandis.be/fr/Sharp/1059701-2392-telecommande-de-remplacement-pour-Sharp-RRMCGA178AWSA.html