Mandis shop

RM-SR10AV

Original	Rechange
Power	Power
Function	Menu
Sleep	Sleep
Play CD	Play
Tuner/Band	TV/R
< > Deck A	Smart
< > Deck B	Media
D.Skip	AV
Check	Dual
Clear	Exit
I<<</Tuning-	I<<
>>I/Tuning+	>>I
<<	<<
>>	>>
Stop	Stop
Pause	Pause
Play MD	Shift + Play

Original	Rechange
Pause MD	Shift + Pause
Stop MD	Shift + Stop
Up/File Select	Up
Down	Down
Right/Flash	Right
Left/Loop	Left
On/Off	Ok
Pro logic On/Off	Options
T Tone On/Off	Back
DSP	Text
Center Level+	Ch +
Center Level-	Ch -
Rear Level+	Blue
Rear Level-	Yellow
Vol+	Vol +
Vol-	Vol -

https://telecommandes-mandis.be/fr/Sony/1059943-81885-telecommande-de-remplacement-pour-Sony-RM-SR10AV-141812821.html