Original	Rechange
Mute	Mute / Dimmer
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
REC	Rec / Rec Mode
0 / AV	0
0 / AV	AV / Input / RDS
OPT	Setup / OPT /
Red / <<	<< / Tune-
Red / <<	Red / Netflix / Search

Original	Rechange
Green / Stop	Stop / Hold
Green / Stop	Green / APP / Repeat
Yellow /	Play / Slow
Yellow /	Yellow / YouTube / Repeat
Blue / Aspect /	Picture / Format
Blue / Aspect /	Blue / Prime Video / Random
Blue / Aspect /	>> / Tune+
Up	Up
Left	Left
OK	OK
Right	Right
Down	Down
SFI / EPG	Guide / EPG / -/--
Exit / Recall	Exit / Cancel / Clear
Exit / Recall	Back / Return
Info	Info / Angle
Prog +	CH+ / Page+

Original	Rechange	Original	Rechange
TV / Radio	TV/ Radio /		
Vol -	Vol -		
Prog -	CH- / Page-		
Menu	Menu / Home		
Vol +	Vol +		
TXT / Mix	Text / Goto		
Still	Pause / Step / Freeze		
PIP	D. Menu / Top		
Sound	Sound / Title		
SAT1	SHIFT + 2		
SAT2	SHIFT + 3		
TV	SHIFT + 1		
Sleep	Sleep / Timer		

Original		Rechange	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
REC	REC	REC MODE	Rec / Rec Mode
0 AV	0 / AV	RDS AV INPUT	AV / Input / RDS
0 AV	0 / AV	HDMI - SAT 0	0
OPT	OPT	OPT-TOOLS SETUP	Setup / OPT /
	Red / <<	TUNE-	<< / Tune-
	Red / <<	NETFLIX SEARCH	Red / Netflix / Search

Original		Rechange	
	Green / Stop	APP REPEAT	Green / APP / Repeat
	Green / Stop	HOLD	Stop / Hold
	Yellow /	SLOW	Play / Slow
	Yellow /	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue / >> /	TUNE+	>> / Tune+
	Blue / >> /	FORMAT PICTURE	Picture / Format
	Blue / >> /	Prime Video RANDOM	Blue / Prime Video / Random
	Up		Up
	Left		Left
ok	OK	OK	OK
	Right		Right
	Down		Down
SFI EPG	SFI / EPG	-/-- GUIDE EPG	Guide / EPG / -/--
EXIT	Exit / Recall	CLEAR EXIT CANCEL	Exit / Cancel / Clear
EXIT	Exit / Recall	RETURN BACK	Back / Return
INFO	Info	ANGLE INFO	Info / Angle
+	Prog +	+ CH PAGE	CH+ / Page+

Original		Rechange	
TV RADIO	TV / Radio	PROGRAM TV/ RADIO	TV/ Radio /
+	Vol -	VOL −	Vol -
− PROG	Prog -	CH PAGE −	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
−	Vol +	+ VOL	Vol +
TXT	TXT / Mix	GOTO TEXT	Text / Goto
STILL	Still	STEP-FREEZE II	Pause / Step / Freeze
PIP	PIP	TOP MENU D.MENU	D. Menu / Top
SOUND	Sound	TITLE SOUND	Sound / Title
SAT1	SAT1	SHIFT + DVD 2	Shift + 2
SAT2	SAT2	SHIFT + CD-STB 3	Shift + 3
TV	TV	SHIFT + TV 1	Shift + 1
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer

Original	Rechange

Original		Rechange	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
REC	REC	REC MODE	Rec / Rec Mode
0 AV	0 / AV	RDS AV INPUT	AV / Input / RDS
0 AV	0 / AV	HDMI - SAT 0	0
OPT	OPT	OPT-TOOLS SETUP	Setup / OPT /
	Red / <<	NETFLIX SEARCH	Red / Netflix / Search
	Red / <<	TUNE-	<< / Tune-

Original		Rechange	
	Green / Stop	APP REPEAT	Green / APP / Repeat
	Green / Stop	HOLD	Stop / Hold
	Yellow /	SLOW	Play / Slow
	Yellow /	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue / >> /	Prime Video RANDOM	Blue / Prime Video / Random
	Blue / >> /	FORMAT PICTURE	Picture / Format
	Blue / >> /	TUNE+	>> / Tune+
	Up		Up
	Left		Left
ok	OK	OK	OK
	Right		Right
	Down		Down
SFI EPG	SFI / EPG	-/-- GUIDE EPG	Guide / EPG / -/--
EXIT	Exit / Recall	CLEAR EXIT CANCEL	Exit / Cancel / Clear
EXIT	Exit / Recall	RETURN BACK	Back / Return
INFO	Info	ANGLE INFO	Info / Angle
+	Prog +	+ CH PAGE	CH+ / Page+

Original	Rechange	Original	Rechange
TV / Radio	TV/ Radio /		
Vol -	Vol -		
Prog -	CH- / Page-		
Menu	Menu / Home		
Vol +	Vol +		
TXT / Mix	Text / Goto		
Still	Pause / Step / Freeze		
PIP	D. Menu / Top		
Sound	Sound / Title		
SAT1	Shift + 2		
SAT2	Shift + 3		
TV	Shift + 1		
Sleep	Sleep / Timer		