Mandis shop

EUR646552

Original		Rechange	
OFF	Off		Power
	A1	A	Red
I<< CD			I<<
>>I CD			>>I
Play CD		PLAY MODE	Play
Pause CD			Pause
■/CLEAR	Stop/Clear CD		Stop
CD PLAY MODE	CD Play Mode	ECO 3D	3D
BAND	Band	SEARCH TV/R	TV/R
PRESET	Preset Tune Down	CH −	Ch -
TUNE	Preset Tune Up	+ CH	Ch +
TUNE +	Tune+		Right
TUN	Tune-		Left
XBS	XBS	HOME SMART	Smart
S.VIRTUALIZER	S.Virtualizer	SOUND DUAL	Dual
POWER BLASTER	Power Blaster	APP MEDIA	Media
VOLUME +	Volume+	+ VOL	Vol +

Original		Rechange	
VOLU	Volume-	VOL −	Vol -
SLEEP	Sleep	PROG SLEEP	Sleep

https://telecommandes-mandis.be/fr/Panasonic/1060222-92425-telecommande-de-remplacement-pour-Panasonic-EUR646552.html