Mandis shop

Panasonic 200094

Original		Rechange		Original	Rechange
POWER	POWER	Shift +	Shift + Power		
POWER	POWER	Power			
MENU	INPUT NEXT	Source	Source		
SHUTTER SHUT	SHUT /	Video Comp	Comp / Video		
ASPECT	ASPECT	Aspect Eco	Eco / Aspect		
ZOOM + 6	D. ZOOM +	Play +	+ / Play		
5	D. ZOOM -	Stop —	- / Stop		
PAGE UP	UP		Up		
PAGE DOWN	DOWN		Down		
	LEFT		Left		
	RIGHT		Right		
ENTER	ENTER	Enter	Enter		
AUTO SETUP	AUTO SETUP	Auto	Auto		
FREEZE	FREEZE	Timer Freeze	Freeze / Timer		
0 USER	USER	Mute Blank	Blank / Mute		
1 STD	STD	Mode	Mode		

https://telecommandes-mandis.be/fr/Panasonic/1061115-66200-telecommande-de-remplacement-pour-Panasonic-N2QAGB000024.html