Mandis shop

RRMCG0144AWSA

| Original | | Rechange | |
|---|---|---|---|
| ON/STAND-BY | On/Standby | Power | |
| VOLUME | Vol+ | VOL + | |
| VOLUME | Vol- | VOL - | |
| X-BASS/EQUALIZER | X-Bass/Equalizer | HOME SMART | |
| VIDEO/AUX | Video/AUX | A | |
| TAPE (1↔2) | Tape (1↔2) | D | |
| TUNER (BAND) | Tuner(Band) | B | |
| C D | CD | C | |
| ●II | Rec/Pause Tape 2 | REC MODE ● | |
| ◀◀ | << Tape 2 | « | |
| ▶▶ | >> Tape 2 | » | |
| TAPE 2 ▶ | Play Tape 2 | ◀ | |
| ▶ TAPE 1 | Play Tape 1 | ▶ | |
| TAPE 1 ■ TAPE 2 | Stop Tape | OK | |
| PRESET | Tuner Preset Up | + CH | |
| PRESET | Tuner Preset | CH − | |
| PTY. TI | PTY TI | RETURN BACK | |

| Original | | Rechange | |
|---|---|---|---|
| G1 | Disc CD 1 | 1 | |
| G2 | Disc CD 2 | 2 | |
| G3 | Disc CD 3 | 3 | |
| DISC SKIP | Disc Skip | APP MEDIA | |
| ⏮ | I<<</<< CD | « | |
| ⏭ | >>/>>I CD | » | |
| ■ | Stop CD | ■ | |
| ▶ | Play CD | PLAY MODE ▶ | |
| MEMORY | Memory CD | ECO 3D | |
| CLEAR | Clear | CLEAR EXIT | |
| RANDOM | Random | SEARCH TV/R | |
| II | Pause CD | II | |

https://telecommandes-mandis.be/fr/Sharp/1061610-2982-telecommande-de-remplacement-pour-Sharp-RRMCG0144AWSA.html