Mandis shop

RMT-AH410U

Original		Rechange	
	Power		Power
INPUT	Input	TIMER AV	AV
AUTO SOUND	Auto Sound	HOME SMART	Smart
STANDARD	Standard	SETTINGS OPT	Options
CINEMA	Cinema	APP MEDIA	Media
MUSIC	Music	SOUND DUAL	Dual
VOICE	Voice	SEARCH TV/R	TV/R
NIGHT	Night	CLEAR EXIT	Exit
	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -
	Mute	MUTE	Mute
BASS	Bass	AD SUBT	Subt
PLAY MODE	Play Mode	SHIFT + PLAY MODE	Shift + Play
AUDIO	Audio	SHIFT + SOUND DUAL	Shift + Dual
	Up		Up
	Down		Down
ENTER	Enter	OK	Ok

Original		Rechange	
	Play	PLAY MODE	Play
	Pause		Pause
	>>I		>>I
	I<<		I<<

https://telecommandes-mandis.be/fr/Sony/1061634-92595-telecommande-de-remplacement-pour-Sony-RMT-AH410U-1-493-358-11.html