Original	Rechange	Original	Rechange
Power ON/Off	Power	Volume-	Vol -
CD Play	Play / Slow	Display	Display / Media
CD Pause	Pause / Step / Freeze	Vol Rs-/Effect	CH- / Page-
CD Rewind	<< / Tune-	Pr 1	1
CD F.FWD	>> / Tune+	Pr 2	2
Tape 2 Pre./eq	Subtitle / EQ	Pr 3	3
6 Ch/Geq	Eject / Surround	Pr 4	4
Sleep	Sleep / Timer	Pr 5	5
Program	TV/Radio /	Pr 6	6
Store/Center-	D.Menu / Top	Pr 7	7
CD/Theater	AV / Input / RDS	Pr 8	8
Mode	Menu / Home	Pr 9	9
Tape 1 Hall/Ats	Info / Angle	Pr 0/10	0
Tape 1 Play	OK	Repeat	Green / APP / Repeat
Tape 1 F.FWD	Right	CD Random	Blue / Prime Video / Random
Volume+	Vol +		
Funct./Direct	Smart / List		

Original	Rechange	Original	Rechange
Power ON/Off	Power	Pr 1	1
Mute	Mute / Dimmer	Pr 2	2
CD Play	Play / Slow	Pr 3	3
Stop	Stop / Hold	Pr 4	4
CD Rewind	<< / Tune-	Pr 5	5
CD F.FWD	>> / Tune+	Pr 6	6
Tape 2 Pre./eq	Subtitle / EQ	Pr 7	7
Input/Source	AV / Input / RDS	Pr 8	8
Tape 1 Hall/Ats	Menu / Home	Tuner/Bypass	Red / Netflix / Search
Tape 1 Rew	Left	Band	Green / APP / Repeat
Tape 1 Play	OK	Fm Mode/Disc	Yellow / YouTube / Repeat
Tape 1 F.FWD	Right	Phono/Scan	Blue / Prime Video / Random
Tape 1 Stop	Down		
Volume+	Vol +		
Funct./Direct	Smart / List		
Volume-	Vol -		
CD/Theater	Display / Media		

Original	Rechange	Original	Rechange
Power ON/Off	Power	Program	TV/Radio /
Mute	Mute / Dimmer	Every Pop	D.Menu / Top
CD Play	Play / Slow	6 Ch/Geq	Setup / OPT /
CD Pause	Pause / Step / Freeze	Surround/Test	Text / Goto
Stop	Stop / Hold	Input/Source	AV / Input / RDS
Tape 1 Rec	Rec / Rec Mode	CD/Theater	Menu / Home
CD Rewind	<< / Tune-	Erase/Snooze	Up
CD F.FWD	>> / Tune+	Tape 1 Preset	Info / Angle
Prev./Prog-	I<< / Preset-	Tape 1 Rew	Left
Next/Prog+	>>I / Preset+	Tape 1 Play	OK
Intro	Sound / Title	Tape 1 F.FWD	Right
Classic Track	Audio / Lang I/II	Clear	Exit / Cancel / Clear
Tape 2 Pre./eq	Subtitle / EQ	Tape 1 Stop	Down
Eject	Eject / Surround	Mark/Delete	Back / Return
Edit	Picture / Format	Volume+	Vol +
Woofer/Speed	Zoom / Size	Funct./Direct	Smart / List
Sleep	Sleep / Timer	Index+/Vol Ls+	CH+ / Page+

Original	Rechange
Volume-	VOL – Vol -
Display	MEDIA DISPLAY Display / Media
Index- / Vol Ls-	CH PAGE – CH- / Page-
Pr 1	TV 1 1
Pr 2	DVD 2 2
Pr 3	CD - STB 3 3
Phono/ Scan	VIDEO 4 4
Center	TAPE 5 5
Fm Mode/ Disc	TUNER 6 6
Aux/ Video	AUX - HDD 7 7
Space/ Default 3D	USB 8 8
Tuner / Bypass	BLUETOOTH 9 9
+10/ Next Sv+V	-/-- GUIDE EPG Guide / EPG / -/--
Store/ Center-	HDMI - SAT 0 0
Mode	PC FAV MARKER Fav / Marker / PC
Search/ Center	NETFLIX SEARCH Red / Netflix / Search
Repeat	APP REPEAT Green / APP / Repeat

Original	Rechange
Ubs/ Check	YouTube REPEAT A-B Yellow / YouTube / Repeat
CD Random	Prime Video RANDOM Blue / Prime Video / Random
ON/ Off	SHIFT + Power Shift + Power
Dimmer	SHIFT + DIMMER MUTE Shift + Mute / Dimmer
Preset Pause	SHIFT + STEP - FREEZE Shift + Pause / Step /
Tape 2 REC./ Jazz	SHIFT + REC MODE Shift + Rec / Rec Mode
Tune/ Vol SW+	SHIFT + TUNE- Shift + << /
Tune/ Vol SW-	SHIFT + TUNE+ Shift + >> /
Track- / Echo	SHIFT + PRESET- Shift + I<< / Preset-
Track+/ Karaoke	SHIFT + PRESET+ Shift + >>I / Preset+
Disc 1 Eject	SHIFT + SURROUND Shift + Eject / Surround
Timer/ A. Track	SHIFT + TIMER SLEEP Shift + Sleep / Timer
X- Bass/ Bgm	SHIFT + Shift + Up
Tape 1 Hall/ Ats	SHIFT + ANGLE INFO Shift + Info / Angle
Tape 2	SHIFT + Shift + Left
Tape 2	SHIFT + OK Shift + OK
Tape 2 FF/ AudioR	SHIFT + Shift + Right

Original	Rechange	Original	Rechange
Tape 2	SHIFT + ▼		
Vol Rs+/S. Mode	SHIFT + VOL +		
Vol Rs-/Effect	SHIFT + VOL −		
Disc 2	SHIFT + DVD 2		
Disc 3 Eject	SHIFT + CD-STB 3		
Disc 4 Eject	SHIFT + VIDEO 4		
Disc 5	SHIFT + TAPE 5		
Band	SHIFT + TUNER 6		