Original		Rechange	
	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CANCEL	Cancel	FAV PRE-CH	Pre Ch
PIP	PIP	ECO 3D	3D
+ VOL	Vol+	+ VOL	Vol +
VOL −	Vol-	VOL −	Vol -
MUTE	Mute	MUTE	Mute

Original		Rechange	
BD/SD	BD/SD	HOME SMART	Smart
iPod	iPod	APP MEDIA	Media
RADIO EXT-IN	Ext-In/Radio	SEARCH TV/R	TV/R
SEARCH	<< Slow Search	<<	<<
▶PLAY	Play	PLAY MODE ▶	Play
SEARCH	Slow Search >>	>>	>>
SKIP	I<< Skip/Down	I<<	I<<
PAUSE	Pause	II	Pause
SKIP	Skip >>I/Up	>>I	>>I
STOP	Stop	■	Stop
STATUS	Status	REPEAT TEXT	Text
EXIT	Exit	CLEAR EXIT	Exit
OPTION	Option	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
DIRECT NAVIGATOR TOP MENU	Top Menu/Direct Navigator	DISC NAV LIST	List
START	Start	PICTURE FORMAT	Format
POP-UP MENU	Pop-Up Menu	TOP MENU MENU	Menu

Original		Rechange	
	Up		Up
	Down		Down
	Right/II>		Right
	Left/<II		Left
OK	OK	OK	Ok
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
SOUND -CH SELECT	-CH Select/Sound	-/-- GUIDE	Guide
SURROUND	Surround	AD SUBT	Subt
DISPLAY	Display	DISPLAY INFO	Info
AUDIO	Audio	SOUND DUAL	Dual
TV	Power Tv	SHIFT +	Shift + Power
AV	AV Tv	TIMER AV	AV
+ VOL	Vol+ Tv	SHIFT + + VOL	Shift + Vol +
VOL −	Vol- Tv	SHIFT + VOL −	Shift + Vol -

Original	Rechange