Mandis shop

LG AKB73615610

Original		Rechange	
	Power		Power
BACK	Back	RETURN BACK	Back / Return
HOME	Home	HOME MENU	Menu / Home
	Up		Up
	Left		Left
	OK	OK	OK
	Right		Right
	Down		Down
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze
INFO/ MENU 123	Info/Menu/123	ANGLE INFO	Info / Angle
	Stop	HOLD	Stop / Hold
	I<</<<	TUNE-	<< / Tune-
	>>/>>I	TUNE+	>> / Tune+
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
	Green	APP REPEAT	Green / APP / Repeat

Original		Rechange	
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat

https://telecommandes-mandis.be/fr/LG/1062193-82856-telecommande-de-remplacement-pour-LG-AKB73615610.html