Original		Rechange	
POWER	Power		Power
SOURCE	Source	TIMER AV	AV
HDMI	HDMI	APP MEDIA	Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
MUTE	Mute	MUTE	Mute
CH LIST	CH List	DISC NAV LIST	List

Original		Rechange	
	Vol+	+ VOL	Vol +
	Vol-	VOL –	Vol -
P	P+	+ CH	Ch +
P	P-	CH –	Ch -
HOME	Home	HOME SMART	Smart
MENU	Menu	TOP MENU MENU	Menu
GUIDE	Guide	- / -- GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
CLOCK INFO	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
A	Red	A	Red
B	Green	B	Green

Original		Rechange		Original	Rechange
C	Yellow	C	Yellow		
D	Blue	D	Blue		
DUAL I-II	Dual I-II	SOUND DUAL	Dual		
CONTENT	Content	E-MANUAL D.MENU	D. Menu		
3D	3D	ECO 3D	3D		
ALARM	Alarm	SEARCH TV/R	TV/R		
P.SIZE	P.Size	PICTURE FORMAT	Format		
SUBT.	Subt.	AD SUBT	Subt		
Enter	Enter	OK	Ok		
<<|<<	<<|<<	<<	<<		
Pause	Pause	Pause	Pause		
>>|>>|	>>|>>|	>>	>>		
Play	Play	PLAY MODE	Play		
Rec	Rec	REC MODE	Rec		
Stop	Stop	Stop	Stop		