Original		Rechange	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX1	AUX1	5	5
MEDIA PLAYER	Media Player	6	6
TV AUDIO	TV Audio	7	7
AUX2	AUX2	8	8
TUNER	Tuner	9	9
USB	USB	-/-- GUIDE	Guide
CD	CD	0	0
Bluetooth	Bluetooth	FAV PRE-CH	Pre Ch
.:l:.	.:l:.	HOME SMART	Smart
PHONO	Phono	SHIFT + HOME SMART	Shift + Smart
INTERNET RADIO	Internet Radio	APP MEDIA	Media

Original		Rechange	
CH / PAGE	CH / Page Up	+ CH	Ch +
CH / PAGE	CH / Page Down	CH –	Ch -
ECO	Eco	ECO 3D	3D
MUTE	Mute	MUTE	Mute
VOLUME	Vol+	+ VOL	Vol +
VOLUME	Vol-	VOL –	Vol -
INFO	Info	DISPLAY INFO	Info
OPTION	Option	SETTINGS OPT	Options
	Up		Up
	Left		Left
ENTER	Enter	OK	Ok
	Right		Right
	Down		Down
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
TUNE –	I<<</Tune-		I<<
	Play	PLAY MODE	Play

Original		Rechange		Original	Rechange
►/II	Pause	II	Pause		
TUNE + ►►I	>>ITune+	>>I	>>I		
MOVIE	Green/Movie	B	Green		
1	Smart Select 1	SHIFT + 1	Shift + 1		
SMART 2	Smart Select 2	SHIFT + 2	Shift + 2		
SELECT 3	Smart Select 3	SHIFT + 3	Shift + 3		
4	Smart Select 4	SHIFT + 4	Shift + 4		
MUSIC	Red/Music	A	Red		
GAME	Blue/Game	D	Blue		
PURE	Yellow/Pure	C	Yellow		

Original		Rechange	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX1	AUX1	5	5
MEDIA PLAYER	Media Player	6	6
TV AUDIO	Tv Audio	7	7
AUX2	AUX2	8	8
TUNER	Tuner	9	9
USB	USB	-/-- GUIDE	Guide
CD	CD	0	0
Bluetooth	Bluetooth	FAV PRE-CH	Pre Ch
.:l:.	.:l:.	HOME SMART	Smart
PHONO	Phono	SHIFT + HOME SMART	Shift + Smart
INTERNET RADIO	Internet Radio	APP MEDIA	Media

Original		Rechange	
CH / PAGE	CH / Page Up	+ CH	Ch +
CH / PAGE	CH / Page Down	CH –	Ch -
VOLUME	Vol+	+ VOL	Vol +
VOLUME	Vol-	VOL –	Vol -
MUTE	Mute	MUTE	Mute
	Up		Up
	Left		Left
ENTER	Enter	OK	Ok
	Right		Right
	Down		Down
BACK	Back	RETURN BACK	Back
TUNE –	I<<</Tune-		I<<
►/II	Play	PLAY MODE ►	Play
►/II	Pause	II	Pause
TUNE +	>>I/Tune+		>>I
1	Smart Select 1	SHIFT + 1	Shift + 1
SMART 2	Smart Select 2	SHIFT + 2	Shift + 2

Original	Rechange	Original	Rechange
SELECT 3 Smart Select 3	SHIFT + 3 Shift + 3		
4 Smart Select 4	SHIFT + 4 Shift + 4		