Original		Rechange	
STANDBY/ON	On / Standby		Power
1 V1	Input Selector V1	TV 1	1
2 V2	Input Selector V2	VIDEO 4	4
3 V3	Input Selector V3	AUX - HDD 7	7
5 MULTI CH	Input Selector Multi CH	USB 8	8
6 DVD	Input Selector	DVD 2	2
7 TAPE	Input Selector	TAPE 5	5
8 TUNER	Input Selector Tuner	TUNER 6	6
9 CD	Input Selector CD	CD - STB 3	3
0 DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
CLR SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
I/⏻	Power Tv	SHIFT + ⏻	Shift + Power
VOL	Vol+ Tv	SHIFT + + VOL	Shift + Vol+
+ CH DISC	CH/Disc/Album	+ CH PAGE	CH+ / Page+
VOL	Vol+	+ VOL	Vol+
INPUT	Input Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
VOL	Vol- Tv	SHIFT + VOL −	Shift + Vol-

Original		Rechange	
CH DISC ALBUM −	CH/Disc/Album-	CH PAGE −	CH- / Page-
VOL	Vol-	VOL −	Vol-
GUIDE TOP MENU	Guide/Top	-/-- GUIDE EPG	Guide / EPG / -/--
GUIDE TOP MENU	Guide/Top	TOP MENU D.MENU	D.Menu / Top
▲	Up	▲	Up
PREVIOUS MENU MUTING	Muting	DIMMER MUTE	Mute / Dimmer
◄ PLAYLIST	Left	◄	Left
ENTER	Enter	OK	OK
► PLAYLIST	Right	►	Right
RETURN	Return	RETURN BACK	Back / Return
▼	Down	▼	Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
⏸	Pause	STEP - FREEZE ⏸	Pause / Step / Freeze
►	Play	SLOW ▶	Play / Slow
■	Stop	HOLD ■	Stop / Hold
◄◄	<<	TUNE- ◄◄	<< / Tune-
►►	>>	TUNE+ ►►	>> / Tune+

Original	Rechange	Original	Rechange
I<<	PRESET- I<< / Preset-		
>>I	PRESET+ >>I / Preset+		
Listening Mode Stereo	EQ SUBTITLE Subtitle / EQ		
Listening Mode Surround	SURROUND Eject / Surround		
Listening Mode <	TITLE SOUND Sound / Title		
Listening Mode >	LANG I/II AUDIO Audio / Lang I/II		
Test Tone	NETFLIX SEARCH Red / Netflix / Search		
CH Sel	APP REPEAT Green / APP / Repeat		
Level-	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Level+	Prime Video RANDOM Blue / Prime Video / Random		
Display	MEDIA DISPLAY Display / Media		
L.Night	SIZE ZOOM Zoom / Size		
Cine FLTR	FORMAT PICTURE Picture / Format		

Original		Rechange	
STANDBY/ON	Power		Power
1 V1	1	TV 1	1
2 V2	2	DVD 2	2
3 V3	3	CD-STB 3	3
4 V4	4	VIDEO 4	4
5 MULTI CH	5	TAPE 5	5
6 DVD	6	TUNER 6	6
7 TAPE	7	AUX-HDD 7	7
8 TUNER	8	USB 8	8
9 CD	9	BLUETOOTH 9	9
+10	+10/10/-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0 DIMMER	0/11	HDMI-SAT 0	0
CLR SLEEP	CLR	CLEAR EXIT CANCEL	Exit / Cancel / Clear
GUIDE TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
	Up		Up
PREVIOUS MENU MUTING	Previous Menu/Muting	HOME MENU	Menu / Home
PREVIOUS MENU MUTING	Previous Menu/Muting	DIMMER MUTE	Mute / Dimmer

Original		Rechange	
PLAYLIST	Left/Playlist/Cat-		Left
ENTER	Enter	OK	OK
PLAYLIST	Right/Playlist/Cat		Right
RETURN	Return	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	SHIFT + EQ SUBTITLE	Shift + Subtitle / EQ
LISTENING SURROUND	Surround	SHIFT + SURROUND	Shift + Eject / Surround
G MODE	< Listening Mode	SHIFT + TITLE SOUND	Shift + Sound / Title
	Listening Mode >	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II

Original	Rechange	Original	Rechange
AUDIO / TEST TONE — Audio	LANG I/II / AUDIO — Audio / Lang I/II		
SUBTITLE / CH SEL — Subtitle	EQ / SUBTITLE — Subtitle / EQ		
RANDOM / LEVEL- — Random	Prime Video / RANDOM — Blue / Prime Video / Random		
REPEAT / LEVEL+ — Repeat	APP / REPEAT — Green / APP / Repeat		
DISPLAY — Display	MEDIA / DISPLAY — Display / Media		
PLAY MODE / VCR — VCR	SHIFT + VIDEO 4 — Shift + 4		
PLAY MODE / VCR — Play Mode VCR	FORMAT / PICTURE — Picture / Format		
L NIGHT / DVD — DVD	SHIFT + DVD 2 — Shift + 2		
CINE FLTR / HDD — HDD	SHIFT + AUX - HDD 7 — Shift + 7		

Original		Rechange	
STANDBY/ON	On / Standby		Power
1 V1	1	TV 1	1
2 V2	2	DVD 2	2
3 V3	3	CD-STB 3	3
4 V4	4	VIDEO 4	4
5 MULTI CH	5	TAPE 5	5
6 DVD	6	TUNER 6	6
7 TAPE	7	AUX-HDD 7	7
8 TUNER	8	USB 8	8
9 CD	9	BLUETOOTH 9	9
+10	+10/10/-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0 DIMMER	0/11	HDMI-SAT 0	0
CLR SLEEP	12	PC FAV MARKER	Fav / Marker / PC
CH DISC ALBUM +	Disc+	CH PAGE +	CH+ / Page+
VOL ▲	Vol+	VOL +	Vol+
CH DISC ALBUM −	Disc-	CH PAGE −	CH- / Page-
VOL ▼	Vol-	VOL −	Vol-

Original		Rechange	
⏸	Pause	STEP-FREEZE ⏸	Pause / Step / Freeze
►	Play	SLOW ►	Play / Slow
■	Stop	HOLD ■	Stop / Hold
◄◄	<<	TUNE- ◄◄	<< / Tune-
►►	>>	TUNE+ ►►	>> / Tune+
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
STEREO	Stereo	EQ SUBTITLE	Subtitle / EQ
LISTENING SURROUND	Surround	SURROUND ⏏	Eject / Surround
G MODE ◄	< Listening Mode	TITLE SOUND	Sound / Title
►	Listening Mode >	LANG I/II AUDIO	Audio / Lang I/II
RANDOM LEVEL-	Random	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT LEVEL+	Repeat	APP REPEAT	Green / APP / Repeat
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Original		Rechange	
STANDBY/ON	Power		Power
1 V1	1	TV 1	1
2 V2	2	DVD 2	2
3 V3	3	CD-STB 3	3
4 V4	4	VIDEO 4	4
5 MULTI CH	5	TAPE 5	5
6 DVD	6	TUNER 6	6
7 TAPE	7	AUX-HDD 7	7
8 TUNER	8	USB 8	8
9 CD	9	BLUETOOTH 9	9
+10	+10/10/-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0 DIMMER	0/11	HDMI-SAT 0	0
CH DISC	CH+	CH PAGE +	CH+ / Page+
CH DISC ALBUM	CH-	CH PAGE −	CH- / Page-
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold

Original		Rechange	
	<<	TUNE-	<< / Tune-
STEREO	Stereo	EQ SUBTITLE	Subtitle / EQ
LISTENING SURROUND	Surround	SURROUND	Eject / Surround
G MODE	< Listening Mode	TITLE SOUND	Sound / Title
	Listening Mode >	LANG I/II AUDIO	Audio / Lang I/II
PLAY MODE VCR	Play Mode	TOP MENU D.MENU	D.Menu / Top
L.NIGHT DVD	L.Night	TIMER SLEEP	Sleep / Timer