Mandis shop

Yamaha RAS15

Original		Rechange	
AMP	Power AMP		Power
CD	Power CD	SHIFT +	Shift + Power
OPEN/CLOSE	Open/Close	ZOOM	Eject
CD DIRECT AMP	CD Direct AMP	HOME SMART	Smart
PURE DIRECT	Pure Direct	APP MEDIA	Media
CD	CD	1	1
COAXIAL	Coaxial	2	2
OPTICAL	Optical	3	3
LINE 1	Line 1	4	4
LINE 2	Line 2	5	5
LINE 3	Line 3	6	6
TUNER	Tuner	7	7
PHONO	Phono	8	8
USB	USB	9	9
BAND	Band	SEARCH TV/R	TV/R
TUNING	Tuning >>		Right
TUNING	<< Tuning		Left

Original		Rechange	
PRESET	Preset >	+ CH	Ch +
PRESET	< Preset	CH −	Ch -
MEMORY	Memory	OK	Ok
	<<	<<	<<
	>>	>>	>>
	>>I	>>I	>>I
	I <<	I <<	I <<
	Pause	II	Pause
	Play	PLAY MODE ▶	Play
	Stop	■	Stop
VOLUME	Volume+	+ VOL	Vol +
VOLUME	Volume-	VOL −	Vol -
MUTE	Mute	MUTE	Mute

https://telecommande-mandis.be/fr/Yamaha/1643-165-telecommande-de-remplacement-pour-Yamaha-RAS15.html