| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| CBL/SAT | CBL/SAT | 1 | 1 |
| MEDIA PLAYER | Media Player | 2 | 2 |
| Blu-ray | Blu-ray | 3 | 3 |
| GAME | Game | 4 | 4 |
| AUX1 | AUX1 | 5 | 5 |
| AUX2 | AUX2 | 6 | 6 |
| PHONO | Phono | 7 | 7 |
| TV AUDIO | TV Audio | 8 | 8 |
| TUNER | Tuner | 9 | 9 |
| USB | USB | -/-- GUIDE | Guide |
| Bluetooth | Bluetooth | 0 | 0 |
| INTERNET RADIO | Internet Radio | FAV PRE-CH | Pre Ch |
| | Micro | HOME SMART | Smart |
| CH / PAGE | CH/Page Up | + CH | Ch + |
| CH / PAGE | CH/Page Down | CH – | Ch - |

| Original | | Rechange | |
|---|---|---|---|
| ECO | Eco | ECO 3D | 3D |
| VOLUME | Volume Up | + VOL | Vol + |
| VOLUME | Volume Down | VOL – | Vol - |
| MUTE | Mute | MUTE | Mute |
| INFO | Info | DISPLAY INFO | Info |
| OPTION | Option | SETTINGS OPT | Options |
| BACK | Back | RETURN BACK | Back |
| SETUP | Setup | TOP MENU MENU | Menu |
| ►/II | Play | PLAY MODE ► | Play |
| ▲ | Up | ▲ | Up |
| ▼ | Down | ▼ | Down |
| ► | Right | ► | Right |
| ◄ | Left | ◄ | Left |
| ENTER | Enter | OK | Ok |
| TUNE – I◄◄ | I<<</Tune- | I◄◄ | I<< |
| ►/II | Pause | II | Pause |
| TUNE + ►►I | >>I/Tune+ | ►►I | >>I |

| Original | | Rechange | |
|---|---|---|---|
| 1 | Quick Select 1 | E-MANUAL D.MENU | D. Menu |
| 2 | Qucki Select 2 | REPEAT TEXT | Text |
| 4 | Quick Select 4 | TIMER AV | AV |
| 3 | Quick Select 3 | ZOOM ⏏ | Eject |
| MOVIE | Green/Movie | A | Red |
| MUSIC | Red/Music | B | Green |
| GAME | Blue/Game | D | Blue |
| PURE | Yellow/Pure | C | Yellow |

| Original | Rechange |
|---|---|
| | |

| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| SLEEP | Sleep | PROG SLEEP | Sleep |
| CBL/SAT | CBL/SAT | 1 | 1 |
| MEDIA PLAYER | Media Player | 2 | 2 |
| Blu-ray | Blu-ray | 3 | 3 |
| GAME | Game | 4 | 4 |
| AUX1 | AUX1 | 5 | 5 |
| AUX2 | AUX2 | 6 | 6 |
| PHONO | Phono | 7 | 7 |
| TV AUDIO | TV Audio | 8 | 8 |
| TUNER | Tuner | 9 | 9 |
| USB | USB | -/-- GUIDE | Guide |
| Bluetooth | Bluetooth | 0 | 0 |
| INTERNET RADIO | Internet Radio | FAV PRE-CH | Pre Ch |
| | Micro | HOME SMART | Smart |
| CH / PAGE | CH/Page Up | + CH | Ch + |
| CH / PAGE | CH/Page Down | CH – | Ch - |

| Original | | Rechange | |
|---|---|---|---|
| VOLUME | Volume Up | + VOL | Vol + |
| VOLUME | Volume Down | VOL – | Vol - |
| MUTE | Mute | MUTE | Mute |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| ENTER | Enter | OK | Ok |
| BACK | Back | RETURN BACK | Back |
| TUNE – | I<<</Tune- | | I<< |
| | Play | PLAY MODE | Play |
| | Pause | | Pause |
| TUNE + | >>I/Tune+ | | >>I |
| 1 | Quick Select 1 | E-MANUAL D.MENU | D. Menu |
| 2 | Quick Select 2 | REPEAT TEXT | Text |
| 3 | Quick Select 3 | ZOOM | Eject |
| 4 | Quick Select 4 | TIMER AV | AV |