Original		Rechange	
MODE	Mode		Power
EPG OSD	EPG/OSD	-/-- GUIDE EPG	Guide / EPG / -/--
TV/MUSIC REPEAT	Tv/Musci/Repea	PROGRAM TV/ RADIO	TV/Radio /
PIC	PIC	FORMAT PICTURE	Picture / Format
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
FAVORITE PR TITLE	Title/Favorite PR	TITLE SOUND	Sound / Title
MEMORY MENU	Menu/Memory	HOME MENU	Menu / Home
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Rechange	
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
EXIT ZOOM	Zoom/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
I<<	I<<	PRESET- I<<	I<< / Preset-
I<<	I<<	SHIFT + PRESET- I<<	Shift + I<< / Preset-
>>I	>>I	SHIFT + PRESET+ >>I	Shift + >>I / Preset+
>>I	>>I	PRESET+ >>I	>>I / Preset+
CH-	CH-	CH PAGE –	CH- / Page-
<<	<<	SHIFT + TUNE- <<	Shift + << /
<<	<<	TUNE- <<	<< / Tune-
CH+	CH+	+ CH PAGE	CH+ / Page+
>>	>>	SHIFT + TUNE+ >>	Shift + >> /
>>	>>	TUNE+ >>	>> / Tune+
ENTER	Enter	OK	OK
TELETEXT ANGLE	Angle/Teletext	GOTO TEXT	Text / Goto
GUIDE SLOW	Slow/Guide	SHIFT + SLOW ▶	Shift + Play /
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II

Original	Rechange	Original	Rechange
Play/Pause	Play / Slow		
Stop/PR List	Stop / Hold		
PG Up/Info	Up		
PG DN/Sleep	Down		