| Original | | Rechange | |
|---|---|---|---|
| MODE | Mode | | Power |
| EPG OSD | EPG/OSD | -/-- GUIDE EPG | Guide / EPG / -/-- |
| TV/MUSIC REPEAT | Tv/Musci/Repea | PROGRAM TV/ RADIO | TV/Radio / |
| PIC | PIC | FORMAT PICTURE | Picture / Format |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI - SAT 0 | 0 |
| FAVORITE PR TITLE | Title/Favorite PR | TITLE SOUND | Sound / Title |
| MEMORY MENU | Menu/Memory | HOME MENU | Menu / Home |
| SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / Tools |

| Original | | Rechange | |
|---|---|---|---|
| SUBTITLE | Subtitle | EQ SUBTITLE | Subtitle / EQ |
| EXIT ZOOM | Zoom/Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| I<< | I<< | PRESET- I<< | I<< / Preset- |
| I<< | I<< | SHIFT + PRESET- I<< | Shift + I<< / Preset- |
| >>I | >>I | SHIFT + PRESET+ >>I | Shift + >>I / Preset+ |
| >>I | >>I | PRESET+ >>I | >>I / Preset+ |
| CH- | CH- | CH PAGE – | CH- / Page- |
| << | << | SHIFT + TUNE- << | Shift + << / |
| << | << | TUNE- << | << / Tune- |
| CH+ | CH+ | + CH PAGE | CH+ / Page+ |
| >> | >> | SHIFT + TUNE+ >> | Shift + >> / |
| >> | >> | TUNE+ >> | >> / Tune+ |
| ENTER | Enter | OK | OK |
| TELETEXT ANGLE | Angle/Teletext | GOTO TEXT | Text / Goto |
| GUIDE SLOW | Slow/Guide | SHIFT + SLOW ▶ | Shift + Play / |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Play/Pause | Play / Slow | | |
| Stop/PR List | Stop / Hold | | |
| PG Up/Info | Up | | |
| PG DN/Sleep | Down | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |