Original		Rechange	
Power		Power	
e/Energy Saving		SHIFT + OK	Shift + OK
AV Mode		GOTO TEXT	Text / Goto
Input		RDS AV INPUT	AV / Input / RDS
TV		PROGRAM TV/ RADIO	TV/Radio /
1		TV 1	1
2 ABC		DVD 2	2
3 DEF		CD - STB 3	3
4 GHI		VIDEO 4	4
5 JKL		TAPE 5	5
6 MNO		TUNER 6	6
7 PQRS		AUX - HDD 7	7
8 TUV		USB 8	8
9 WXYZ		BLUETOOTH 9	9
0		HDMI - SAT 0	0
LIST		LIST SMART	Smart / List
Q.VIEW		OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Rechange	
MARK FAV	FAV/Mark	PC FAV MARKER	Fav / Marker / PC
CHAR/NUM RATIO	Ratio	FORMAT PICTURE	Picture / Format
DELETE MUTE	Mute/Delete	DIMMER MUTE	Mute / Dimmer
+ VOL	Vol+	+ VOL	Vol+
VOL −	Vol-	VOL −	Vol-
CH	CH+	+ CH PAGE	CH+ / Page+
CH	CH-	CH PAGE −	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
NetCast	Netcast	MEDIA DISPLAY	Display / Media
Q.MENU	Q.Menu	TOP MENU D.MENU	D.Menu / Top
Up	Up	Up	Up
Down	Down	Down	Down
Left	Left	Left	Left
Right	Right	Right	Right
ENTER	Enter	OK	OK
BACK	Back	RETURN BACK	Back / Return
SIMPLINK	Simplink	SIZE ZOOM	Zoom / Size

Original		Rechange	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
■	Stop	HOLD ■	Stop / Hold
▶	Play	SLOW ▶	Play / Slow
❚❚	Pause	STEP - FREEZE ❚❚	Pause / Step / Freeze
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+

Original	Rechange