Mandis shop

Sony RM-S6

Original		Rechange		Original		Rechange	
CD	CD	3	3	–	Vol -	VOL –	Vol -
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer				
POWER	Power		Power				
▶	Play	SLOW ▶	Play / Slow				
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze				
■	Stop	HOLD ■	Stop / Hold				
⏏	Open/Close	SURROUND ⏏	Eject / Surround				
⏮	I <<	TUNE- ⏪	<< / Tune-				
⏭	>>I	TUNE+ ⏩	>> / Tune+				
TAPE	Tape	TAPE 5	5				
TUNER	Tuner	TUNER 6	6				
SHIFT	Shift	APP REPEAT	Green / APP / Repeat				
PHONO	Phono	TV 1	1				
+ PRESET	Preset +	PRESET+ ⏭	>>I / Preset +				
+	Vol +	+ VOL	Vol +				
VIDEO/AUX	Video/AUX	VIDEO 4	4				
PRESET –	Preset -	PRESET- ⏮	I << / Preset -				

https://telecommandes.mandis.be/fr/Sony/10589-518-telecommande-de-replacement-pour-Sony-RM-S6-145431.html