Mandis shop

Sony RM-J701

Original		Rechange	
	Eject	SURROUND	Eject / Surround
DISPLAY	Display	MEDIA DISPLAY	Display / Media
RESET	Counter Reset	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MEMORY	Counter	HOME MENU	Menu / Home
MONITOR	Monitor	LIST SMART	Smart / List
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
	Rec	REC MODE	Rec / Rec Mode
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	Rec Stop	TITLE SOUND	Sound / Title
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	CD Pause	OK	OK
	CD I<<		Left
	CD >>I		Right

Original		Rechange	
STOP	Stop CD	SHIFT + HOLD	Shift + Stop /
START	Start CD Synchro	SHIFT + SLOW	Shift + Play /
STANDBY	Standby CD		Power

https://telecommandes-mandis.be/fr/Sony/1066124-82271-telecommande-de-remplacement-pour-Sony-RM-J701-146531411.html