Mandis shop

RM-SCEX1

Original		Rechange	
I/⏻	Power	⏻	Power
CD ▶	Play CD	SLOW ▶	Play / Slow
⏸	Pause CD	STEP-FREEZE ⏸	Pause / Step / Freeze
■	Stop CD	HOLD ■	Stop / Hold
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
⏮	I<</-	PRESET- ⏮	I<< / Preset-
⏭	>>I/+	PRESET+ ⏭	>>I / Preset+
STEREO/ MONO	Stereo/Mono	LANG I/II AUDIO	Audio / Lang I/II
OPEN/ CLOSE	Open/Close	SURROUND ⏏	Eject / Surround
TUNING MODE	Tuning Mode	FORMAT PICTURE	Picture / Format
TUNER/BAND	Tuner/Band	PROGRAM TV/ RADIO	TV/Radio /
FUNCTION	Function	HOME MENU	Menu / Home
MEMORY ▲	Up/Memory	▲	Up
TIMER SET	Left/Timer Set	◀	Left
ENTER	Enter/On/Off	OK	OK
TIMER SELECT	Right/Timer Select	▶	Right

Original		Rechange	
SLEEP ▼	Down/Sleep	▼	Down
VOL +	Vol+	+ VOL	Vol+
DSG	DSG	LIST SMART	Smart / List
	Vol-	VOL −	Vol-
DISPLAY	Display	MEDIA DISPLAY	Display / Media
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
PLAY MODE	Play Mode	Prime Video RANDOM	Blue / Prime Video / Random
SURROUND	Surround	SHIFT + SURROUND ⏏	Shift + Eject / Surround

https://telecommandes-mandis.be/fr/Sony/1066154-95747-telecommande-de-remplacement-pour-Sony-RM-SCEX1.html