Mandis shop

Sharp 92L33X000XX010

Original		Rechange	
ON / STAND-BY	On/Stand-by		Power
X-BASS	X-Bass	LANG I/II AUDIO	Audio / Lang I/II
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
CLOCK / TIMER	Clock/Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
CD ▶/II	Play/Pause CD	SLOW ▶	Play / Slow
USB / SD ▶/II	Play/Pause	STEP-FREEZE II	Pause / Step / Freeze
TUNER (BAND)	Tuner (Band)	PROGRAM TV/RADIO	TV/Radio /
PRESET-	I<<</<<Preset	PRESET- ⏮	I<< / Preset-
PRESET+	Preset Up/>>/>>I	PRESET+ ⏭	>>I / Preset+
STOP	Stop	HOLD ■	Stop / Hold
TUNING / FOLDER ▼	Tuning/Folder	▼	Down
TUNING / FOLDER ▲	Tuning/Folder Up	▲	Up
TAPE	Tape	SHIFT + TAPE 5	Shift + 5
RDS ASPM / PTY	ASPM/PTY RDS	OPT-TOOLS SETUP	Setup / OPT /
RDS DISP	Disp RDS	MEDIA DISPLAY	Display / Media
REC	Rec	REC MODE	Rec / Rec Mode
1	1	TV 1	1

Original		Rechange	
2	2	DVD 2	2
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
3	3	CD - STB 3	3
4	4	VIDEO 4	4
MEMORY / DISP	Memory/Disp	NETFLIX SEARCH	Red / Netflix / Search
5	5	TAPE 5	5
6	6	TUNER 6	6
+ VOL	Vol+	+ VOL	Vol+
7	7	AUX - HDD 7	7
8	8	USB 8	8
VOL –	Vol-	VOL –	Vol-
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
EQUALIZER	Equalizer	SIZE ZOOM	Zoom / Size

https://telecommandes-mandis.be/fr/Sharp/1067330-3204-telecommande-de-remplacement-pour-Sharp-92L33X000XX010.html