Mandis shop

CU-DC010

Original		Rechange	
POWER	Power		Power
	CD Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Tape I Stop	HOLD	Stop / Hold
REC	Tape II REC	REC MODE	Rec / Rec Mode
	Tape I <<	TUNE-	<< / Tune-
	Tape I >>	TUNE+	>> / Tune+
TRACK	CD I<< Track	PRESET-	I<< / Preset-
TRACK	CD >>I Track	PRESET+	>>I / Preset+
PHONO	Function Phono	LANG I/II AUDIO	Audio / Lang I/II
WAKE-UP	Wake Up	FORMAT PICTURE	Picture / Format
SNOOZE	Snooze	SIZE ZOOM	Zoom / Size
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
DISC	CDDisc	PROGRAM TV/RADIO	TV/Radio /
VIDEO	Function Video	OPT-TOOLS SETUP	Setup / OPT /
	CD Stop	GOTO TEXT	Text / Goto
	Tape I <		Left

Original		Rechange	
	Tape I >		Right
VOLUME +	Volume+	VOL +	Vol+
STATION +	Tuner Station+	CH + PAGE	CH+ / Page+
VOLUME	Volume-	VOL −	Vol-
STATION	Tuner Station-	CH − PAGE	CH- / Page-
TUNER	Tuner	TUNER 6	6
	CD Pause	SHIFT + STEP-FREEZE	Shift + Pause / Step /
	Tape II Stop	SHIFT + HOLD	Shift + Stop /
	Tape II <<	SHIFT + TUNE-	Shift + << /
	Tape II >>	SHIFT + TUNE+	Shift + >> /
	Tape II <	SHIFT +	Shift + Left
	Tape II >	SHIFT +	Shift + Right

https://telecommandes-mandis.be/fr/Pioneer/1067447-96814-telecommande-de-remplacement-pour-Pioneer-CU-DC010.html