Original		Rechange	
VTR	VTR		Power
SCANNER ON/OFF	Scanner On/Off	OPT-TOOLS SETUP	Setup / OPT /
TRANSMIT	Transmit	LIST SMART	Smart / List
PAUSE/STILL	Pause/Still	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
STILL ADV	Still Adv	Prime Video RANDOM	Blue / Prime Video / Random
REW/⊖	<<	TUNE-	<< / Tune-
PLAY	Play	SLOW	Play / Slow
⊕/FF	>>	TUNE+	>> / Tune+
REC	Rec	REC MODE	Rec / Rec Mode
-	-		Left
SEARCH	Search	OK	OK
CH	+		Right
CLOCK/ COUNTER	Clock/Counter	PC FAV MARKER	Fav / Marker / PC
TAPE REMAIN	Tape Remain	MEDIA DISPLAY	Display / Media
RESET	Reset	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MONITOR	Monitor	TOP MENU D.MENU	D.Menu / Top Menu

Original		Rechange	
AV LINK	AV Link	PROGRAM TV/ RADIO	TV/Radio /
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
INDE	I<< Index	PRESET-	I<< / Preset-
NDEX	Index >>I	PRESET+	>>I / Preset+
TRACKING	Tracking/V-Lock-	CH PAGE	CH- / Page-
NG/V-LOCK	Tracking/V-Lock+	CH PAGE	CH+ / Page+
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
ZERO STOP	Zero Stop	GOTO TEXT	Text / Goto
TIME SEARCH	Time Search	NETFLIX SEARCH	Red / Netflix / Search
AUDIO OUT	Audio Out	LANG I/II AUDIO	Audio / Lang I/II
SU 1	1	TV 1	1
MO 2	2	DVD 2	2
TU 3	3	CD - STB 3	3
WE 4	4	VIDEO 4	4
TH 5	5	TAPE 5	5
FR 6	6	TUNER 6	6
RECORDING UP SP	Recording SP/LP	FORMAT PICTURE	Picture / Format

Original		Rechange	
SA 7	7	AUX - HDD 7	7
SU~SA 8	8	USB 8	8
MO~SA 9	9	BLUETOOTH 9	9
MO~FR 0	0	HDMI - SAT 0	0
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
TIMER REC	Timer Rec	TIMER SLEEP	Sleep / Timer
PAL/MESECAM	Pal/Mesecam	SIZE ZOOM	Zoom / Size

Original	Rechange

Original		Rechange	
VTR	VTR		Power
SCANNER ON/OFF	Scanner On/Off	PROGRAM TV/RADIO	TV/Radio /
TRANSMIT	Transmit	OPT-TOOLS SETUP	Setup / OPT /
PAUSE/STILL	Pause/Still	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
STILL ADV	Still Adv	YouTube REPEAT A-B	Yellow / YouTube / Repeat
REW/⊖	<<	TUNE-	<< / Tune-
PLAY	Play	SLOW	Play / Slow
⊕/FF	>>	TUNE+	>> / Tune+
REC	Rec	REC MODE	Rec / Rec Mode
-	-		Left
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
CH	+		Right
RESET	Reset	RETURN BACK	Back / Return
AV LINK	AV Link	RDS AV INPUT	AV / Input / RDS
INPUT SELECT	Input Select	LIST SMART	Smart / List
INDE	I<< Index	PRESET-	I<< / Preset-

Original		Rechange	
INDEX	Index >>I	PRESET+	>>I / Preset+
TRACKING	Tracking/V-Lock-	CH PAGE	CH- / Page-
NG/V-LOCK	Tracking/V-Lock+	CH PAGE	CH+ / Page+
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
ZERO STOP	Zero Stop	CLEAR EXIT CANCEL	Exit / Cancel / Clear
AUDIO OUT	Audio Out	DIMMER MUTE	Mute / Dimmer
SU 1	1	TV 1	1
MO 2	2	DVD 2	2
TU 3	3	CD-STB 3	3
WE 4	4	VIDEO 4	4
TH 5	5	TAPE 5	5
FR 6	6	TUNER 6	6
RECORDING LP SP	Recording LP/SP	FORMAT PICTURE	Picture / Format
SA 7	7	AUX-HDD 7	7
SU~SA 8	8	USB 8	8
MO~SA 9	9	BLUETOOTH 9	9
MO~FR 0	0	HDMI-SAT 0	0

Original		Rechange	
	-/--		Guide / EPG / -/--
	Timer Rec		Text / Goto

Original	Rechange