Original		Rechange	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
LANG	Lang	LANG I/II AUDIO	Audio / Lang I/II
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
GAME	Game	FORMAT PICTURE	Picture / Format
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
TV/RADIO	Tv/Radio	PROGRAM TV/ RADIO	TV/Radio /
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
0	0	HDMI - SAT 0	0
RECALL	Recall	RETURN BACK	Back / Return

Original		Rechange	
DEV.LIST	Dev.List	MEDIA DISPLAY	Display / Media
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
TEXT	Text	GOTO TEXT	Text / Goto
AUTO	Auto	OPT-TOOLS SETUP	Setup / OPT /
MENU	Menu	HOME MENU	Menu / Home
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
INFO	Info	ANGLE INFO	Info / Angle
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
Group CH+/▲	Up	▲	Up
Group CH+/▲	CH+	+ CH PAGE	CH+ / Page+
V- ◀	Left	◀	Left
V- ◀	Vol-	VOL −	Vol-
ENTER	Enter	OK	OK
V+ ▶	Right	▶	Right
V+ ▶	Vol+	+ VOL	Vol+
CH-/▼	CH-	CH PAGE −	CH- / Page-

Original		Rechange		Original	Rechange
CH-/▼	Down		Down		
FILELIST	Filelist	LIST SMART	Smart / List		
REC	Rec	REC MODE	Rec / Rec Mode		
	Stop	HOLD	Stop / Hold		
	Play	SLOW	Play / Slow		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
FAV.	<<	TUNE-	<< / Tune-		
DEL.	>>	TUNE+	>> / Tune+		
MOVE	I<<	PRESET-	I<< / Preset-		
LOCK	>>I	PRESET+	>>I / Preset+		
DAILY	Red/FAV./Daily	NETFLIX SEARCH	Red / Netflix / Search		
WEEKLY	Green/Del./Weekl	APP REPEAT	Green / APP / Repeat		
P.INFO	Yellow/Move/P.Inf	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
TIMER	Blue/Look/Timer	Prime Video RANDOM	Blue / Prime Video / Random		