Mandis shop

Sony RMT-AM330U

Original		Rechange	
SCORE	Score	LIST SMART	Smart / List
DISPLAY	Display	MEDIA DISPLAY	Display / Media
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
	Power		Power
PLAY MODE	Play Mode	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT/ FM MODE	Repeat/FM	APP REPEAT	Green / APP / Repeat
PARTY LIGHT	Party Light	NETFLIX SEARCH	Red / Netflix / Search
LIGHT MODE	Light Mode	YouTube REPEAT A-B	Yellow / YouTube / Repeat
REC TO USB	Rec To USB	REC MODE	Rec / Rec Mode
	Up		Up
TUNER MENU	Tuner Menu	HOME MENU	Menu / Home
	Left/Folder-		Left
	OK	OK	OK
	Right/Folder+		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
OPTIONS	Options	OPT-TOOLS SETUP	Setup / OPT / Tools

Original		Rechange	
FUNCTION	Function	TOP MENU D.MENU	D.Menu / Top
MEGA BASS	Mega Bass	TITLE SOUND	Sound / Title
SOUND FIELD	Sound Field	LANG I/II AUDIO	Audio / Lang I/II
TUNING–	<<</Tuning-	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
TUNING+	>>/Tuning+	TUNE+	>> / Tune+
PRESET–	I<<</Preset-	PRESET-	I<< / Preset-
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
PRESET+	>>I/Preset+	PRESET+	>>I / Preset+
VOCAL FADER	Vocal Fader	DIMMER MUTE	Mute / Dimmer
VOL	Vol+	VOL	Vol+
KEY CONTROL #	Key Control #	CH PAGE	CH+ / Page+
MIC ECHO	Mic Echo	PROGRAM TV/ RADIO	TV/Radio /
VOL	Vol-	VOL	Vol-
b	Key Control b	CH PAGE	CH- / Page-

https://telecommandes-mandis.be/fr/Sony/1067636-95625-telecommande-de-remplacement-pour-Sony-RMT-AM330U-149329411.html