Original		Rechange	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX	AUX	5	5
MEDIA PLAYER	Media Player	6	6
iPod/USB	iPod / USB	7	7
CD	CD	8	8
TUNER	Tuner	9	9
NETWORK	Network	-/-- GUIDE	Guide
TV AUDIO	TV Audio	0	0
INTERNET RADIO	Internet Radio	FAV PRE-CH	Pre Ch
FAV 1	Favorite Station 1	SHIFT + 1	Shift + 1
FAVORITE STATION 2	Favorite Station 2	SHIFT + 2	Shift + 2
TION 3	Favorite Station 3	SHIFT + 3	Shift + 3

Original		Rechange	
CH / PAGE	CH + / Page +	+ CH	Ch +
CH / PAGE	CH - / Page -	CH −	Ch -
MUTE	Mute	MUTE	Mute
VOLUME	Volume +	+ VOL	Vol +
VOLUME	Volume -	VOL −	Vol -
INFO	Info	DISPLAY INFO	Info
OPTION	Option	SETTINGS OPT	Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
TUNE −	I<< / Tune -		I<<
TUNE −	I<< / Tune -		<<
	Play / Pause	PLAY MODE	Play

Original		Rechange		Original	Rechange
►/II	Play / Pause	II	Pause		
TUNE + ►►I	>>I / Tune +	>>I	>>I		
TUNE + ►►I	>>I / Tune +	>>	>>		
MOVIE	Green / Movie	B	Green		
MUSIC	Red / Music	A	Red		
GAME	Blue / Game	D	Blue		
PURE	Yellow / Pure	C	Yellow		

Original		Rechange	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL / SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX	AUX	5	5
MEDIA PLAYER	Media Player	6	6
iPod/USB	iPod / USB	7	7
CD	CD	8	8
TUNER	Tuner	9	9
NETWORK	Network	-/-- GUIDE	Guide
TV AUDIO	TV Audio	0	0
INTERNET RADIO	Internet Radio	FAV PRE-CH	Pre Ch
FAV 1	Favorite Station 1	SHIFT + 1	Shift + 1
FAVORITE STATION 2	Favorite Station 2	SHIFT + 2	Shift + 2
TION 3	Favorite Station 3	SHIFT + 3	Shift + 3

Original		Rechange	
CH / PAGE	CH+ / Page +	+ CH	Ch +
CH / PAGE	CH - / Page -	CH –	Ch -
MUTE	Mute	MUTE	Mute
VOLUME	Volume +	+ VOL	Vol +
VOLUME	Volume -	VOL –	Vol -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
BACK	Back	RETURN BACK	Back
TUNE –	I<< / Tune -		I<<
TUNE –	I<< / Tune -		<<
	Play / Pause	PLAY MODE	Play
	Play / Pause		Pause
TUNE +	>>I / Tune +		>>I
TUNE +	>>I / Tune +		>>