Original	Rechange	Original	Rechange
Power	Power	>>/ RGB2	Shift + 8
[i +]	Info	Menu	Menu
AV1	AV	[>I <] / Recall	Pre Ch
AV1	Shift + 1	Up	Up
Rec/ AV2	Shift + 2	Left	Left
Rec/ AV2	Rec	OK	Ok
Stop/ AV3	Shift + 3	Right	Right
Stop/ AV3	Stop	Down	Down
Play/ AV4	Shift + 4	♪/ S. Mode	Shift + Dual
Play/ AV4	Play	(I) / P. Mode	Shift + Format
AV5	Shift + 5	Vol +	Vol +
AV5	Shift + AV	Vol -	Vol -
Pause/ AV6	Shift + 6	I / I I	Dual
Pause/ AV6	Pause	Mute	Mute
<</ RGB1	Shift + 7	P+	Ch +
<</ RGB1	<<	P-	Ch -
>>/ RGB2	>>	1	1

Original		Rechange	
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
2-4-12	[I]/2-4-12	RETURN BACK	Back
	[I ≡]	-/-- GUIDE	Guide
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	[≡i]	SETTINGS OPT	Options
	[≡x]	SEARCH TV/R	TV/R

Original		Rechange	
SLIDE SHOW	[. . .]/Slide Sho	AD SUBT	Subt
ROTATE	[≡?]/Rotate	ECO 3D	3D
	[≡]	REPEAT TEXT	Text
	[<>]	PICTURE FORMAT	Format
SWIVEL	Swivel	HOME SMART	Smart
PHOTO	Photo	APP MEDIA	Media

Original		Rechange	
	Power		Power
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Menu		Menu
	Stop		Stop
	Play		Play
	Pause		Pause
	<<		<<
	>>		>>
	P+		Ch +
	P-		Ch -

Original	Rechange

Original		Rechange	
	Power		Power
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Vol +		Vol +
	Vol -		Vol -
	P+		Ch +
	P-		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7

Original		Rechange	
	8		8
	9		9
	0		0