Original	Rechange	Original	Rechange
Power	Power	Exit	Exit
Mute	Mute	PR+	Ch +
1	1	PR-	Ch -
2	2	Vol +	Vol +
3	3	Vol -	Vol -
4	4	Up	Up
5	5	Down	Down
6	6	Right	Right
7	7	Left	Left
8	8	OK/List	Ok
9	9	↑	>>
0	0	↓	<<
Tv/Radio	TV/R	Pause	Pause
↩PR	Back	Red	Red
EPG	Guide	Green	Green
Menu	Menu	Yellow	Yellow
Info	Info	Blue	Blue

Original		Rechange	
AUDIO	Audio	SOUND DUAL	Dual
TXT	TXT	REPEAT TEXT	Text
[. . .]	[. . .]	AD SUBT	Subt
Audio L/R	Audio L/R	HOME SMART	Smart
[+]	[+]	ECO 3D	3D
FAV	FAV	FAV PRE-CH	Pre Ch
UHF	UHF	APP MEDIA	Media
PAL/NTSC	PAL/NTSC	PICTURE FORMAT	Format
TV/AV	Tv/AV	TIMER AV	AV

Original	Rechange

Original	Rechange	Original	Rechange
Power	Power	Exit	Exit
Mute	Mute	Up/ PR+	Up
1	1	Down/ PR-	Down
2	2	OK/ List	Ok
3	3	Right	Right
4	4	Left	Left
5	5	Vol +	Vol +
6	6	Vol -	Vol -
7	7	↑	Ch +
8	8	↓	Ch -
9	9	Pause	Pause
0	0	[+]	3D
Tv/ Radio	TV/ R	FAV	Pre Ch
↩PR	Back	UHF	Smart
EPG	Guide	PAL/ NTSC	Format
Menu	Menu	TV/ AV	AV
Info	Info	Red	Red

Original		Rechange		Original	Rechange
TXT	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		
AUDIO	Audio	SOUND DUAL	Dual		
TXT	TXT	REPEAT TEXT	Text		
	[...]	AD SUBT	Subt		
	Audio L/R	SHIFT + SOUND DUAL	Shift + Dual		