Original		Rechange	
OPERATE	Operate		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
ADD TIME 5	5	5	5
6	6	6	6
7	7	7	7
DAILY 8	8	8	8
WEEKLY 9	9	9	9
AUX 0	0	0	0
TV/ VIDEO (MONITOR)	Tv/ Video	SEARCH TV/R	TV/ R
AUDIO MONITOR	Mute	MUTE	Mute
	' / ' '	SOUND DUAL	Dual
	Tv Vol +	+ VOL	Vol +
	Tv Vol -	VOL −	Vol -
+ TV PROG	Tv Prog+	+ CH	Ch +

Original		Rechange	
TV PROG −	Tv Prog-	CH −	Ch -
	Right		Right
	Left		Left

Original		Rechange	
OPERATE	Operate		Power
STORE	Store	HOME SMART	Smart
CH SET	CH Set	APP MEDIA	Media
RE-VIEW	Review	-/-- GUIDE	Guide
CLOCK	Clock	RETURN BACK	Back
C.MEMORY DISPLAY	C. Memory/Display	DISPLAY INFO	Info
MODE	Mode	PICTURE FORMAT	Format
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
ADD TIME 5	5	5	5
6	6	6	6
7	7	7	7
DAILY 8	8	8	8
WEEKLY 9	9	9	9
AUX 0	0	0	0

Original		Rechange	
C.RESET CANCEL	C. Reset/Cancel	CLEAR EXIT	Exit
+ START	Start+	+ VOL	Vol +
TIMER	Timer	TIMER AV	AV
START —	Start-	VOL —	Vol -
+ STOP	Stop+	▲	Up
STOP —	Stop-	▼	Down
+ DATE	Date+	▶	Right
DATE —	Date-	◀	Left
+ TV PROG	Tv Prog+/Up	+ CH	Ch +
TV PROG —	Tv Prog-/Down	CH —	Ch -
	'/''	SOUND DUAL	Dual
AUDIO MONITOR	Audio Monitor	MUTE	Mute
TV/ VIDEO (MONITOR)	Tv/Video	SEARCH TV/R	TV/R
◀◀	<<	<<	<<
▶	Play	PLAY MODE ▶	Play
▶▶	>>	>>	>>
●	Rec	REC MODE ●	Rec

Original	Rechange	Original	Rechange
Stop	Stop		
Pause	Pause		
Scene Finder	3D		
Prog/Check	Menu		
Prog	Sleep		
OK	Ok		
>>I / Push Jog+	>>I		
I <<I / Push Jog-	I <<		

Original		Rechange	
OPERATE	Operate		Power
STORE	Store	HOME SMART	Smart
CH SET	CH Set	APP MEDIA	Media
RE-VIEW	Review	-/-- GUIDE	Guide
CLOCK	Clock	RETURN BACK	Back
C.MEMORY DISPLAY	C. Memory Display	DISPLAY INFO	Info
MODE	Mode	PICTURE FORMAT	Format
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
ADD TIME 5	5	5	5
6	6	6	6
7	7	7	7
DAILY 8	8	8	8
WEEKLY 9	9	9	9
AUX 0	0	0	0

Original		Rechange	
C.RESET CANCEL	C. Reset / Cancel	CLEAR EXIT	Exit
TIMER	Timer	TIMER AV	AV
+ START	Start +	+ VOL	Vol +
START —	Start -	VOL —	Vol -
+ STOP	Stop+		Up
STOP —	Stop-		Down
+ DATE	Date+		Right
DATE —	Date-		Left
+ TV PROG	Tv Prog+/ Up	+ CH	Ch +
TV PROG —	Tv Prog- / Down	CH —	Ch -
	' / ' '	SOUND DUAL	Dual
AUDIO MONITOR	Audio/ Monitor	MUTE	Mute
TV/ VIDEO (MONITOR)	Tv/ Video	SEARCH TV/R	TV/ R
	<<	<<	<<
	Play	PLAY MODE	Play
	>>	>>	>>
	Rec	REC MODE	Rec

Original		Rechange	
	Stop		Stop
	Pause		Pause
	Scene Finder	ECO 3D	3D
	Prog Check	TOP MENU MENU	Menu
	Prog	PROG SLEEP	Sleep
	OK	OK	Ok
	>>I / Push Jog+	>>I	>>I
	I <<I Push Jog-	I <<	I <<

Original	Rechange