Mandis shop

JVC RM-V717U

Original		Rechange	
START /STOP	Star/Stop		Power
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	Rec/Pause	REC MODE	Rec / Rec Mode
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	<< VCR	PRESET-	I<< / Preset-
	>> VCR	PRESET+	>>I / Preset+
FADE	Fade	OPT-TOOLS SETUP	Setup / OPT /
EFFECT	Effect	GOTO TEXT	Text / Goto
IN/OUT	In/Out	RDS AV INPUT	AV / Input / RDS
	Up		Up
	Left		Left
	Right		Right
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down

Original		Rechange	
ON/OFF	On/Off R.A. Edit	LIST SMART	Smart / List
T	T	CH PAGE +	CH+ / Page+
DISPLAY	Display	MEDIA DISPLAY	Display / Media
W	W	CH PAGE −	CH- / Page-
	[>]/Insert	DVD 2	2
	A.Dub	CD - STB 3	3
SNAPSHOT	Snapshot	TUNER 6	6
ON/OFF	On/Off	SHIFT +	Shift + Power
	Play VCR	SHIFT + SLOW	Shift + Play /
	Pause VCR	SHIFT + STEP - FREEZE	Shift + Pause / Step /
	Stop VCR	SHIFT + HOLD	Shift + Stop /
	<I Slow	SHIFT + TUNE-	Shift + << /
	I> Slow	SHIFT + TUNE+	Shift + >> /

https://telecommandes-mandis.be/fr/JVC/1067606-17396-telecommande-de-remplacement-pour-JVC-RM-V717U.html