Mandis shop

Lauson CL144

Original		Rechange		Original	Rechange
FIND	Find	HOME SMART	Smart		
INFO	Info	DISPLAY INFO	Info		
REP/ INTRO/RAN	Rep/Intro/Ran	OK	Ok		
PROGRAM	Program	PROG SLEEP	Sleep		
REC	Rec	REC MODE	Rec		
▶II	Play	PLAY MODE ▶	Play		
▶II	Pause	II	Pause		
■	Stop	■	Stop		
I◀◀SKIP/SEA	I<<	K<	I<<		
/SEARCH ▶▶I	Skip/Search	>>I	>>I		
+10	+10	+ CH	Ch +		
-10	-10	CH –	Ch -		
SOURCE	Source	TIMER AV	AV		
TS	TS	SOUND DUAL	Dual		

https://telecommandes-mandis.be/fr/Lauson/1058039-85022-telecommande-de-remplacement-pour-Lauson-MP3-Digital-CL144.html