Original		Rechange	
STANDBY	Standby		Power
MUTE	Mute	MUTE	Mute
PIN	P/N	HOME SMART	Smart
OPEN/CLOSE	Open/Close	ZOOM	Eject
<<	<<	<<	<<
>>	>>	>>	>>
Play/Pause	Play/Pause	PLAY MODE	Play
STOP	Stop		Stop
I<<	I<<	I<<	I<<
>>I	>>I	>>I	>>I
SETUP	Setup	SETTINGS OPT	Options
SOURCE	Source	TIMER AV	AV
INFO	Info	DISPLAY INFO	Info
RETURN/EXIT	Return/Exit	CLEAR EXIT	Exit
CH+	CH+	+ CH	Ch +
CH-	CH-	CH −	Ch -
CH+	Up		Up

Original		Rechange	
CH-	Down		Down
VOL +	Right		Right
VOL -	Left		Left
OK	OK	OK	Ok
VOL +	Vol +	+ VOL	Vol +
VOL -	Vol -	VOL −	Vol -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
SLOW	Slow	RETURN BACK	Back

Original		Rechange	
GOTO	Goto	APP MEDIA	Media
PROGRAM	Program	PROG SLEEP	Sleep
TITLE/TTX	Title/TTX	REPEAT TEXT	Text
AUDIO	Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
REPEAT	Red/Repeat	A	Red
A-B	Green/A-B	B	Green
MENU	Yellow/Menu	C	Yellow
ANGLE	Blue/Angle	D	Blue
EPG	EPG	-/-- GUIDE	Guide
FAVORITE	Favorite	FAV PRE-CH	Pre Ch
TV/RADIO	Tv/Radio	SEARCH TV/R	TV/R
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject

Original	Rechange