| Original | | Rechange | |
|---|---|---|---|
| ON/STANDBY | On / Standby | | Power |
| 1 DVD | Input Selector | 1 | 1 |
| 2 VCR/DVR | Input Selector VCR/DVR | 2 | 2 |
| 3 CBL/SAT | Input Selector CBL/SAT | 3 | 3 |
| 4 GAME/TV | Input Selector GAME/TV | 4 | 4 |
| 5 TAPE | Input Selector | 5 | 5 |
| 6 TUNER | Input Selector Tuner | 6 | 6 |
| 7 CD | Input Selector CD | 7 | 7 |
| 8 PHONO | Input Selector Phono | 8 | 8 |
| +10 D.TUN | D.TUN | PLAY MODE | Play |
| 0 DIMMER | Dimmer | SHIFT + MUTE | Shift + Mute |
| CLR SLEEP | Sleep | PROG SLEEP | Sleep |
| TUNING MODE | Band | | Pause |
| TUNING MODE | FM Mode | | Stop |
| | Tuning+ | | >> |
| TUNING | Tuning- | | << |
| DISC ALBUM | Disc/Album+ | CH + | Ch + |

| Original | | Rechange | |
|---|---|---|---|
| DISC ALBUM + | Preset+ | | >>I |
| DISC ALBUM − PRESET | Disc/Album- | CH − | Ch - |
| DISC ALBUM − PRESET | Preset- | | I<< |
| VOL | Vol+ | VOL + | Vol + |
| VOL | Vol- | VOL − | Vol - |
| MENU MUTING | Muting | MUTE | Mute |
| TOP MENU SP A/B | SP A/B | TOP MENU MENU | Menu |
| | Up | | Up |
| PLAYLIST CATEGORY | Left | | Left |
| ENTER | Enter | OK | Ok |
| PLAYLIST CATEGORY | Right | | Right |
| | Down | | Down |
| SETUP | Setup | SETTINGS OPT | Options |
| RETURN | Return | RETURN BACK | Back |
| | Tape Rev. Play | SHIFT + | Shift + Pause |
| | Tape Play | SHIFT + PLAY MODE | Shift + Play |
| | Tape Stop | SHIFT + | Shift + Stop |

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| | Tape << | SHIFT + | Shift + << | | |
| | Tape >> | SHIFT + | Shift + >> | | |
| | Tape I<< | SHIFT + | Shift + I<< | | |
| | Tape >>I | SHIFT + | Shift + >>I | | |
| ANGLE STEREO | Stereo | A | Red | | |
| PLAY MODE DIRECT | Direct | B | Green | | |
| RANDOM PURE A | Pure A | C | Yellow | | |
| DISPLAY DISPLAY | Display | DISPLAY INFO | Info | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |