Mandis shop

Panasonic N2QAEC000023

Original		Rechange	
START/ STOP	Start/Stop	Power	
PHOTO SHOT	Photo Shot	SRC	Source
EXT DISPLAY	Ext/Display	9 DISP	9 / Disp
DATE/ TIME	Date/Time	GOTO	Eject / GOTO
ZOOM + T VOL	Zoom T/Vol+	V+	V+
VOL – W	Zoom W/Vol-	V–	V-
SEARCH	<< Search	SLOW	<<
PLAY	Play	BAND	Play / Band
SEARCH	Search >>	STEP	>>
STILL ADV	<I Still ADV	-	-
PAUSE	Pause	IIANG	IIAng
STILL ADV	Still ADV I>	+	+
SKIP	I<< Skip	EQ	I<
STOP	Stop	RANDOM	Stop / Random
SKIP	Skip >>I	CLEAR	>I
	Delete/Spam	3 EXIT	3 / Exit
MENU	Menu	2 MENU	2 / Menu

Original		Rechange	
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	OK

https://telecommandes-mandis.be/fr/Panasonic/1056912-9523-telecommande-de-remplacement-pour-Panasonic-N2QAEC000023.html