Original	Rechange	Original	Rechange
[+]	Zoom / Size	Left	Left
Power	Power	Right	Right
Source/[?]	AV / Input / RDS	Vol +	Vol +
>>	>> / Tune+	Vol -	Vol -
Red/Rec	Red / Netflix / Search	Mute	Mute / Dimmer
Green	Green / APP / Repeat	P+	CH+ / Page+
<<	<< / Tune-	P-	CH- / Page-
Yellow	Yellow / YouTube / Repeat	1	1
Stop	Stop / Hold	2	2
Blue	Blue / Prime Video / Random	3	3
Play	Play / Slow	4	4
Radio	TV/Radio /	5	5
[≡]	Text / Goto	6	6
[ ]	D.Menu / Top	7	7
Menu	Menu / Home	8	8
Up	Up	9	9
Down	Down	0	0

Original	Rechange	Original	Rechange
[i+]	Info / Angle		
I-II	Audio / Lang I/II		
[1l2]	Subtitle / EQ		
[:≡]	Guide / EPG / -/--		
[<>]	Picture / Format		
P<P	Fav / Marker / PC		
♪/Smart	Smart / List		
[ ]/Smart	Display / Media		

Original	Rechange
Power SAT	SHIFT + Power: Shift + Power
Power	Power
Source/[?]	RDS AV INPUT: AV / Input / RDS
Source SAT	SHIFT + RDS AV INPUT: Shift + AV / Input / RDS
>>	TUNE+: >> / Tune+
Red SAT	NETFLIX SEARCH: Red / Netflix / Search
<<	TUNE-: << / Tune-
Green SAT	APP REPEAT: Green / APP / Repeat
Yellow SAT	YouTube REPEAT A-B: Yellow / YouTube / Repeat
Stop	HOLD: Stop / Hold
Play	SLOW: Play / Slow
Blue SAT	Prime Video RANDOM: Blue / Prime Video / Random
Radio	PROGRAM TV/RADIO: TV/Radio /
[≡]	GOTO TEXT: Text / Goto
Up	Up
Up SAT	SHIFT + Up: Shift + Up
Down	Down

Original	Rechange
Down SAT	SHIFT + Down: Shift + Down
Left SAT	SHIFT + Left: Shift + Left
Left	Left
Right SAT	SHIFT + Right: Shift + Right
Right	Right
OK SAT	SHIFT + OK: Shift + OK
OK	OK
[ ] SAT	SHIFT + RETURN BACK: Shift + Back / Return
[ ]	RETURN BACK: Back / Return
Menu SAT	TOP MENU D.MENU: D.Menu / Top
Menu	HOME MENU: Menu / Home
Vol +	VOL +: Vol +
Vol -	VOL -: Vol -
Mute	DIMMER MUTE: Mute / Dimmer
P+ SAT	SHIFT + CH PAGE +: Shift + CH+ /
P+	CH PAGE +: CH+ / Page+
P- SAT	SHIFT + CH PAGE -: Shift + CH- / Page-

Original	Rechange
P-	CH- / Page-
1 SAT	Shift + 1
1	1
2 SAT	Shift + 2
2	2
3 SAT	Shift + 3
3	3
4 SAT	Shift + 4
4	4
5 SAT	Shift + 5
5	5
6 SAT	Shift + 6
6	6
7 SAT	Shift + 7
7	7
8 SAT	Shift + 8
8	8

Original	Rechange
9 SAT	Shift + 9
9	9
0 SAT	Shift + 0
0	0
[i+]	Info / Angle
I-II	Audio / Lang I/II
[<>]	Picture / Format
P<P	Fav / Marker / PC

Original		Rechange	
POWER	Power	POWER	Power
>>	>> / Tune+	TUNE+	
<<	<< / Tune-	TUNE-	
Stop	Stop / Hold	HOLD	
Play	Play / Slow	SLOW	
Radio	TV/ Radio /	PROGRAM TV/ RADIO	
[ ]	Back / Return	RETURN BACK	
Up	Up		
Down	Down		
Left	Left		
Right	Right		
Vol +	Vol +	VOL +	
Vol -	Vol -	VOL −	
Mute	Mute / Dimmer	DIMMER MUTE	
P+	CH+ / Page+	CH + PAGE	
P-	CH- / Page-	CH − PAGE	
1	1	TV 1	

Original		Rechange	
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
[i+]	Info / Angle	ANGLE INFO	
I-II	I - II	LANG I/II AUDIO	Audio / Lang I/II

Original	Rechange
Power AMP	SHIFT + Power (Shift + Power)
Power	Power
Source/[?]	AV INPUT (RDS) / AV / Input / RDS
>>	>> / Tune+
>> AMP	>>I / Preset+
Red	NETFLIX (SEARCH) / Red / Netflix / Search
Rec	REC MODE / Rec / Rec Mode
<< AMP	I<< / Preset-
Green	APP (REPEAT) / Green / APP / Repeat
<<	<< / Tune-
Yellow	YouTube (REPEAT A-B) / Yellow / YouTube / Repeat
Stop	HOLD / Stop / Hold
Blue	Prime Video (RANDOM) / Blue / Prime Video / Random
Play	SLOW / Play / Slow
Radio AMP	PROGRAM TV/RADIO / TV/Radio /
[≡] AMP	GOTO TEXT / Text / Goto
[ ]	RETURN BACK / Back / Return

Original	Rechange
Menu	HOME MENU / Menu / Home
Menu AMP	TOP MENU D.MENU / D.Menu / Top
Up AMP	SHIFT + ▲ (Shift + Up)
Up	▲ / Up
Down	▼ / Down
Down AMP	SHIFT + ▼ (Shift + Down)
Left	◀ / Left
Left AMP	SHIFT + ◀ (Shift + Left)
Right	▶ / Right
Right AMP	SHIFT + ▶ (Shift + Right)
OK	OK / OK
OK AMP	SHIFT + OK (Shift + OK)
Vol + AMP	SHIFT + LIST SMART (Shift + Smart / List)
Vol +	VOL + / Vol +
Vol -	VOL - / Vol -
Mute AMP	SHIFT + DIMMER MUTE (Shift + Mute / Dimmer)
Mute	DIMMER MUTE / Mute / Dimmer

Original	Rechange
P+	CH+ / Page+
P+ AMP	Shift + CH+ /
P- AMP	Shift + CH- /
P-	CH- / Page-
1 AMP	Shift + 1
1	1
2 AMP	Shift + 2
2	2
3 AMP	Shift + 3
3	3
4 AMP	Shift + 4
4	4
5 AMP	Shift + 5
5	5
6 AMP	Shift + 6
6	6
7 AMP	Shift + 7

Original	Rechange
7	7
8 AMP	Shift + 8
8	8
9 AMP	Shift + 9
9	9
0 AMP	Shift + 0
0	0
[i+]	Info / Angle
I-II	Audio / Lang I/II
[1I2] AMP	Subtitle / EQ
[+]	Zoom / Size
[<>]	Picture / Format
P<P	Fav / Marker / PC
♪/Smart	Smart / List
[ ]/Smart	Display / Media