| Original | | Rechange | |
|---|---|---|---|
| RECEIVER | Power Receiver | | Power |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| PHASE CTRL | Play | SLOW | Play / Slow |
| MPX | Pause | STEP-FREEZE | Pause / Step / Freeze |
| PQLS | Stop | HOLD | Stop / Hold |
| THX | << | TUNE- | << / Tune- |
| STATUS | >> | TUNE+ | >> / Tune+ |
| TV/DTV | I<< | PRESET- | I<< / Preset- |
| | >>I | PRESET+ | >>I / Preset+ |
| MENU ADV SURR | Adv. Surr. | TITLE SOUND | Sound / Title |
| | Audio | LANG I/II AUDIO | Audio / Lang I/II |
| | iPod CTRL | SURROUND | Eject / Surround |
| A.ATT 8 | A.ATT. | FORMAT PICTURE | Picture / Format |
| HMG | HMG | SIZE ZOOM | Zoom / Size |
| SLEEP 6 | Sleep | TIMER SLEEP | Sleep / Timer |
| SAT TV | TV | PROGRAM TV/RADIO | TV/Radio / |
| | Top Menu | TOP MENU D.MENU | D.Menu / Top Menu |

| Original | | Rechange | |
|---|---|---|---|
| BDR DVR | DVR / BDR | OPT-TOOLS SETUP | Setup / OPT / |
| MCACC 5 | MCACC | GOTO TEXT | Text / Goto |
| INPUT S | ↶ Input Select | RDS AV INPUT | AV / Input / RDS |
| | Home Menu | HOME MENU | Menu / Home |
| | Up | | Up |
| D.ACCESS | D.Access | ANGLE INFO | Info / Angle |
| | Left | | Left |
| | Enter | OK | OK |
| | Right | | Right |
| | T.Edit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| | Down | | Down |
| RETURN | Return | RETURN BACK | Back / Return |
| MASTER VOLUME + | Master Volume | + VOL | Vol+ |
| SIGNAL SEL 4 | Signal Sel | LIST SMART | Smart / List |
| CH LEVEL 7 | CH Level | + CH PAGE | CH+ / Page+ |
| – | Master Volume | VOL – | Vol- |
| INFO DISP | Disp | MEDIA DISPLAY | Display / Media |

| Original | Rechange |
|---|---|
| 2nd Return | CH- / Page- |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| Video | Guide / EPG / -/-- |
| 0 | 0 |
| BD | Fav / Marker / PC |
| Class | Red / Netflix / Search |
| Repeat | Green / APP / Repeat |
| Enter (Class) | Yellow / YouTube / Repeat |
| Random | Blue / Prime Video / Random |

| Original | Rechange |
|---|---|
| Dimmer | Shift + Mute / Dimmer |
| Tune- | Shift + << / |
| Tune+ | Shift + >> / |
| Preset - | Shift + I<< / Preset- |
| Preset + | Shift + >>I / Preset+ |
| Band | Shift + Sound / Title |
| Stereo | Shift + Audio / Lang I/II |
| Auto / Alc / Direct | Shift + Picture / Format |
| ADPT | Shift + TV/Radio / Program |
| MPX | Shift + D.Menu / Top Menu |
| Status | Shift + Setup / OPT / Tools |
| Phase CTRL | Shift + Text / |
| Input Select ↷ | Shift + AV / Input / RDS |
| Standard | Shift + Menu / |
| 2nd Up | Shift + Up |
| 2nd Left | Shift + Left |
| 2nd Enter | Shift + OK |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| 2nd Right | SHIFT + ▶ Shift + Right | | |
| 2nd Down | SHIFT + ▼ Shift + Down | | |
| PQLS | SHIFT + SMART Shift + Smart / List | | |
| INFO DISP 2nd Disp. | SHIFT + DISPLAY Shift + Display / Media | | |
| DVD | SHIFT + 2 Shift + 2 | | |
| CD | SHIFT + 3 Shift + 3 | | |
| VIDEO | SHIFT + 4 Shift + 4 | | |
| TUNER | SHIFT + 6 Shift + 6 | | |
| USB iPod | SHIFT + 8 Shift + 8 | | |
| HDMI | SHIFT + 0 Shift + 0 | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |