Original		Rechange	
	Power		Power
	Source		AV / Input / RDS
	HDMI		Shift + 0
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	--		Zoom / Size
	PRE-CH		Fav / Marker / PC
	Vol +		Vol +
	Vol -		Vol -

Original		Rechange	
	Mute		Mute / Dimmer
	CH List		Shift + Smart / List
	Smart Hub		Smart / List
	Menu		Menu / Home
	Guide		Guide / EPG / -/--
	Tools		Setup / OPT /
	Info		Info / Angle
	Return		Back / Return
	Exit		Exit / Cancel / Clear
	Up		Up
	Enter		OK
	Down		Down
	Right		Right
	Left		Left
A	Red		Red / Netflix / Search
B	Green		Green / APP / Repeat
C	Yellow		Yellow / YouTube / Repeat

Original		Rechange		Original	Rechange
D	Blue	Prime Video / RANDOM	Blue / Prime Video / Random		
Family Story	Family Story	GOTO / TEXT	Text / Goto		
SEARCH	Search	SHIFT + NETFLIX / SEARCH	Shift + Red / Netflix /		
MTS	MTS	EQ / SUBTITLE	Subtitle / EQ		
P.SIZE	P. Size	FORMAT / PICTURE	Picture / Format		
SUPPORT	Support	LANG I/II / AUDIO	Audio / Lang I/II		
CC	CC	PROGRAM / TV/ RADIO	TV/ Radio /		
◀◀	<<	TUNE- / ◀◀	<< / Tune-		
❚❚	Pause	STEP · FREEZE / ❚❚	Pause / Step / Freeze		
▶▶	>>	TUNE+ / ▶▶	>> / Tune+		
●	Rec	REC MODE / ●	Rec / Rec Mode		
▶	Play	SLOW / ▶	Play / Slow		
■	Stop	HOLD / ■	Stop / Hold		
CH	CH+	CH PAGE +	CH+ / Page+		
CH	CH-	CH PAGE −	CH- / Page-		