Original		Rechange	
	Power		Power
WIDE	Wide	PICTURE FORMAT	Format
	Mute	MUTE	Mute
TV/	Tv/Source	SEARCH TV/R	TV/R
▽A·B	▼ A-B	SOUND DUAL	Dual
	→ ←	HOME SMART	Smart
	[.]/[Y]/[≡?]	APP MEDIA	Media
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Rechange	
	-/--/[≡o]	-/-- GUIDE	Guide
CS	CS	FAV PRE-CH	Pre Ch
SURROUND	Red/Surround	A	Red
	Green	B	Green
BASS	Yellow/Bass	C	Yellow
	Blue/Timer	D	Blue
MENU	Menu	TOP MENU MENU	Menu
P⇄P	P↔P	RETURN BACK	Back
P▲	Up		Up
P▲	P+	CH +	Ch +
P▼	P-	CH −	Ch -
P▼	Down		Down
	Right		Right
	Vol +	VOL +	Vol +
	Left/Vol -		Left
F/OK	F/OK	OK	Ok
	O/[≡x]	AD SUBT	Subt

Original		Rechange		Original		Rechange
	[≡♦]	ECO 3D	3D			
	[≡+]	SETTINGS OPT	Options			
TXT/TV	TXT/TV	REPEAT TEXT	Text			
	Rec	REC MODE	Rec			
	Pause		Pause			
	Second Power	SHIFT +	Shift + Power			
	Stop		Stop			
PREV	<<		<<			
	Play	PLAY MODE	Play			
NEXT	>>		>>			

Original		Rechange		Original		Rechange	
	Power		Power				
MENU	Menu	TOP MENU MENU	Menu				
P▲	Up		Up				
P▼	Down		Down				
	Right		Right				
	Left		Left				
F/OK	Enter	OK	Ok				
	Pause		Pause				
NEXT	Next		>>				
	Play	PLAY MODE	Play				
PREV	Prev		<<				
	Stop		Stop				