Mandis shop

RRMCG0144AWSA

Original		Rechange	
ON/STAND-BY	On/Standby	Power	
VOLUME	Vol+	VOL +	
VOLUME	Vol-	VOL -	
X-BASS/EQUALIZER	X-Bass/Equalizer	HOME SMART	
VIDEO/AUX	Video/AUX	A	
TAPE (1↔2)	Tape (1↔2)	D	
TUNER (BAND)	Tuner(Band)	B	
C D	CD	C	
●II	Rec/Pause Tape 2	REC MODE ●	
◀◀	<< Tape 2	«	
▶▶	>> Tape 2	»	
TAPE 2 ▶	Play Tape 2	◀	
▶ TAPE 1	Play Tape 1	▶	
TAPE 1 ■ TAPE 2	Stop Tape	OK	
PRESET	Tuner Preset Up	+ CH	
PRESET	Tuner Preset	CH −	
PTY. TI	PTY TI	RETURN BACK	

Original		Rechange	
G1	Disc CD 1	1	
G2	Disc CD 2	2	
G3	Disc CD 3	3	
DISC SKIP	Disc Skip	APP MEDIA	
⏮	I<<</<< CD	«	
⏭	>>/>>I CD	»	
■	Stop CD	■	
▶	Play CD	PLAY MODE ▶	
MEMORY	Memory CD	ECO 3D	
CLEAR	Clear	CLEAR EXIT	
RANDOM	Random	SEARCH TV/R	
II	Pause CD	II	

https://telecommandes-mandis.be/fr/Sharp/1061610-2982-telecommande-de-remplacement-pour-Sharp-RRMCG0144AWSA.html