Mandis shop

# Sony RMSR5

| Original | | Rechange | |
|---|---|---|---|
| DISC SKIP | Disc Skip | Prime Video / RANDOM | Blue / Prime Video / Random |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| I/⏻ | Power | ⏻ | Power |
| CD ▶ | CD Play | SLOW ▶ | Play / Slow |
| ⏸ | Pause | STEP-FREEZE ⏸ | Pause / Step / Freeze |
| ■ | Stop | HOLD ■ | Stop / Hold |
| TUNER/BAND ▶ | Tuner/Band | YouTube / REPEAT A-B | Yellow / YouTube / Repeat |
| ⏮ | I<< | PRESET- ⏮ | I<< / Preset- |
| ⏭ | >>I | PRESET+ ⏭ | >>I / Preset+ |
| DECK A ▶ | Deck A Play | NETFLIX / SEARCH | Red / Netflix / Search |
| ◀◀ | << | TUNE- ◀◀ | << / Tune- |
| ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ |
| DECK B ▶ | Deck B Play | APP / REPEAT | Green / APP / Repeat |
| CHECK | Check | MEDIA DISPLAY | Display / Media |
| CLEAR | Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| MD ▶ | MD Play | SHIFT + SLOW ▶ | Shift + Play / |
| ⏸ | Pause MD | SHIFT + STEP-FREEZE ⏸ | Shift + Pause / Step / Freeze |

| Original | | Rechange | |
|---|---|---|---|
| ■ | Stop MD | SHIFT + HOLD ■ | Shift + Stop / |
| LOOP | Loop | LIST SMART | Smart / List |
| FLASH | Flash | ANGLE INFO | Info / Angle |
| FUNCTION | Function | HOME MENU | Menu / Home |
| FILE SELECT ▲ | Up | ▲ | Up |
| VOL + | Vol + | + VOL | Vol+ |
| ON/OFF | On /Off | OK | OK |
| ▼ | Down | ▼ | Down |
| VOL − | Vol - | VOL − | Vol- |

https://telecommandes-mandis.be/fr/Sony/1058651-23109-telecommande-de-remplacement-pour-Sony-RM-SR5-147557211.html