Mandis shop

RM-SC3

Original		Rechange	
I / ⏻	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
DISPLAY	Display	DISPLAY INFO	Info
CLOCK/TIMER SELECT	Clock Timer	TIMER AV	AV
CLOCK/TIMER SET	Clock Timer SET	ECO 3D	3D
TUNER MEMORY	Tuner Memory	1	1
PLAY MODE/ TUNING MODE	Play Mode/Tuning Mode	SHIFT + PLAY MODE	Shift + Play
PLAY MODE/ TUNING MODE	Play Mode/Tuning Mode	2	2
REPEAT/ FM MODE	Repeat/FM	3	3
REPEAT/ FM MODE	Repeat/FM	REPEAT TEXT	Text
TAPE	Tape	A	Red
CD	CD	B	Green
TUNER BAND	Tuner Band	C	Yellow
DAB	DAB	D	Blue
FUNCTION	Function	HOME SMART	Smart
I<</-	I<</-	I<<	I<<
>>I/+	>>I/+	>>I	>>I

Original		Rechange	
<<	<<	<<	<<
>>	>>	>>	>>
Play	Play	PLAY MODE	Play
Pause	Pause		Pause
Stop	Stop		Stop
CLEAR	Clear	CLEAR EXIT	Exit
EQ	EQ	APP MEDIA	Media
ENTER	Enter	OK	Ok
VOLUME +	Vol+	VOL +	Vol +
VOLUME -	Vol-	VOL -	Vol -
Album-	Album-	CH -	Ch -
Album+	Album+	CH +	Ch +

https://telecommandes-mandis.be/fr/Sony/1063507-92156-telecommande-de-remplacement-pour-Sony-RM-SCR30.html