Mandis shop

RM-SCEX1

| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| | Play CD | SLOW | Play / Slow |
| | Pause CD | STEP · FREEZE | Pause / Step / Freeze |
| | Stop CD | HOLD | Stop / Hold |
| | << | TUNE- | << / Tune- |
| | >> | TUNE+ | >> / Tune+ |
| | I<</- | PRESET- | I<< / Preset- |
| | >>I/+ | PRESET+ | >>I / Preset+ |
| | Stereo/Mono | LANG I/II AUDIO | Audio / Lang I/II |
| | Open/Close | SURROUND | Eject / Surround |
| | Tuning Mode | FORMAT PICTURE | Picture / Format |
| | Tuner/Band | PROGRAM TV/ RADIO | TV/Radio / |
| | Function | HOME MENU | Menu / Home |
| | Up/Memory | | Up |
| | Left/Timer Set | | Left |
| | Enter/On/Off | OK | OK |
| | Right/Timer Select | | Right |

| Original | | Rechange | |
|---|---|---|---|
| | Down/Sleep | | Down |
| | Vol+ | VOL | Vol+ |
| | DSG | LIST SMART | Smart / List |
| | Vol- | VOL | Vol- |
| | Display | MEDIA DISPLAY | Display / Media |
| | Repeat | APP REPEAT | Green / APP / Repeat |
| | Play Mode | Prime Video RANDOM | Blue / Prime Video / Random |
| | Surround | SHIFT + SURROUND | Shift + Eject / Surround |

Select

https://telecommandes-mandis.be/fr/Sony/1066154-95747-telecommande-de-remplacement-pour-Sony-RM-SCEX1.html