Original		Rechange	
OPEN/CLOSE	Open / Close	SURROUND	Eject / Surround
I/⏻	Power	⏻	Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
SET UP	Set Up	OPT-TOOLS SETUP	Setup / OPT /
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
TV/DVD	TV / DVD	LIST SMART	Smart / List
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
WIDE MODE	Wide Mode	FORMAT PICTURE	Picture / Format
CLEAR -/--	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
0	0	HDMI-SAT 0	0
ENTER	Enter	PC FAV MARKER	Fav / Marker / PC

Original		Rechange	
TV/VIDEO	TV / Video	RDS AV INPUT	AV / Input / RDS
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
VOL +	Vol +	+ VOL	Vol +
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
A↔B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
—	Vol -	VOL —	Vol -
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
ANGLE	Angle	ANGLE INFO	Info / Angle
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
TIME/TEXT	Time / Text	GOTO TEXT	Text / Goto
TIME/TEXT	Time / Text	TIMER SLEEP	Sleep / Timer
STEP ◁II	◁II Step	SHIFT + PRESET- ⏮	Shift + I<< / Preset-
STEP II▷	Step II>	SHIFT + PRESET+ ⏭	Shift + >>I / Preset+
SLOW ◁	◁ Slow	SHIFT + TUNE- ◀◀	Shift + << /
SLOW I▷	Slow I>	SHIFT + TUNE+ ▶▶	Shift + >> /
PREV ⏮	I<< Prev	PRESET- ⏮	I<< / Preset-

Original		Rechange		Original	Rechange
NEXT	Next >>I	PRESET+	>>I / Preset +		
SC	<< Scan	TUNE-	<< / Tune-		
CAN	Scan >>	TUNE+	>> / Tune+		
PLAY	Play	SLOW	Play / Slow		
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze		
STOP	Stop	HOLD	Stop / Hold		
TITLE	Title	TITLE SOUND	Sound / Title		
DVD MENU	DVD Menu	HOME MENU	Menu / Home		
	Up		Up		
	Left		Left		
ENTER	Enter	OK	OK		
	Right		Right		
DISPLAY	Display	MEDIA DISPLAY	Display / Media		
	Down		Down		
RETURN	Return	RETURN BACK	Back / Return		

Original		Rechange	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	-/--		Guide / EPG / -/--
	0		0
	Enter		Fav / Marker / PC
	Repeat		Green / APP / Repeat
	Vol +		Vol +
	TV Prog+		CH+ / Page+
	Vol -		Vol -

Original		Rechange	
	TV Prog-		CH- / Page-