Mandis shop

VibroShaper VIBROSHAPER

Original		Rechange		Original	Rechange
	Power		Power		
	I >	SLOW	Play / Slow		
	I >	STEP-FREEZE	Pause / Step / Freeze		
VEL	Vel + / Speed+		Up		
TPO	TPO- / Time-		Left		
TPO	TPO+ / Time+		Right		
VEL	Vel - / Speed-		Down		
M	M	HOME MENU	Menu / Home		
P	P	ANGLE INFO	Info / Angle		

https://telecommande-remote.com/vibroshaper/1664-363-telecommande-remplacement-pour-vibroshaper.htm